

*Spare parts suitable for: **EMMEPI***

Spare parts suitable for modular ranges




TABLE OF CONTENTS

Open tops (gas/electric)




page 4

Ovens (gas/electric)



page 6

Hot cupboards (electric)



page 7

Fry tops (gas/electric)



page 7


Lava rock grills (gas)



page 8

TABLE OF CONTENTS

Pasta cookers (gas/electric)



page 9

Bains-marie (gas/electric)



page 9

Fryers (gas/electric)



page 10

Baking tipping pan (gas/electric)



page 11

Boiling pans (gas/electric)



page 12

Open tops (gas)



Item	Order	Description	Model	OEM
1	105120	burner base	652	C10046
2	105121	burner ring	653	C10045
3	105122	burner cover	653	C10196



Item	Order	Description	Model	OEM
1	105123	burner base	652	C10049
2	105124	burner ring	653	C10048
3	105125	burner cover/outer	653	C10197
4	105126	burner cover/inner		C10198



Item	Order	Description	Model	OEM
1	105141	burner holder, 3kW		C10273
2	105139	burner base, 3kW	702/704/706 S702/S704/S706	C89438
3	105140	burner cover, 3kW		C10284



Item	Order	Description	Model	OEM
1	105138	burner holder, 3kW	702/704/706	C10274
2	105136	burner base, 3kW	702/704/706	C89437
3	105137	burner cover, 3kW	702/704/706	C10285



Item	Order	Description	Model	OEM
1	105132	burner holder, 3,5kW	E752/E754 E765/E758	C00010
2	105130	burner base, 3,5kW	E902/E904 E906/E908	C99636
3	105131	burner cover, 3,5kW		C00456



Item	Order	Description	Model	OEM
1	105129	burner holder, 5,5kW	E752/E754 E765/E758	C00011
2	105127	burner base, 5,5kW	E902/E904 E906/E908	C99637
3	105128	burner cover, 5,5kW		C00457




Item	Order	Description	Model	OEM
1	105135	burner holder, 7,5kW		C00012
2	105133	burner base, 7,5kW	E902/E904 E906/E908	C99638
3	105134	burner cover, 7,5kW		C00458



Item	Order	Description	Model	OEM
1	101030	ignition unit, 2 outputs	652/653/654	C10167
2	101031	ignition unit, 4 outputs	702/704/706	C10168
3	101032	ignition unit, 6 outputs	S702/S704/S706	C10169




Item	Order	Description	Model	OEM
1	100160	ignition switches		C10250
2	101036	battery holder	652/653/654, 702/704/706, S702/S704/S706	C10166
3	100753	electrode kurz		C10085
3	100754	electrode lang		C10161



Item	Order	Description	Model	OEM
1	102145	thermocouple, 600mm		C10067
1	102146	thermocouple, 750mm	652/653/654	C10065
2	102147	thermocouple, 750mm		C10334
2	102148	thermocouple, 600mm	702/704/706 S702/S704/S706	C10333
3	102149	ground cable		C10362



Item	Order	Description	Model	OEM
1	100069	pilot burner		C00391
2	102039	thermocouple, 320mm	E752 - E758	C00072
2	102042	thermocouple, 850mm	E902 - E908	C00377



Item	Order	Description	Model	OEM
1	100122	pilot burner		C00392
2	100708	electrode	T65_ /T70_ ET7_ /ET9_	C00172
3	100123	ignition cable, 600mm		C00171
4	100005	piezoelectric igniter	ET7_ /ET9_	C00069



Item	Order	Description	Model	OEM
1	101458	gas tap	652_	C10107
2	110810	knob	702_ S702_	C89459 C89433
3	101086	gas tap	E752 - E758	C00085
4	110811	knob	E902 - E908	C99683

Open tops, Solid tops (gas)



Item	Order	Description	Model	OEM
1	105320	burner	T65_	C89458
2	105323	burner	T70_	C89456
3	105326	burner	ET7_ /EST7_ ET9_ /EST9_	C99716



Item	Order	Description	Model	OEM
1	101086	gas tap	T65_	C00085
2	110811	knob	ET7_ /ET9_	C99683
3	102039	thermocouple, 320mm	T65_ /T70	C00072
3	102042	thermocouple, 850mm	ET7_ /ET9_ EST7_ /EST9_	C00377

Open tops (electric)




Item	Order	Description	Model	OEM
1	490016	cooker, Ø180, 2000 W	652E/654E/EF 702E_ /704E_	C10000
1	490020	cooker, Ø220, 2600 W	E752E-/E754E- E756E_	C00208
1	490062	cooker, Ø300, 3500 W	902E_ /904E/906E	C00210
2	490066	cooker 220x220mm, 2600 W	702E_ /704E_	C00637
2	490056	cooker 300x300mm, 3000 W	E902E_	
2	490071	cooker 300x300mm, 4000 W	E904E_	00212
			E906E_	



Item	Order	Description	Model	OEM
1	490092	circuit, 1800 W/1-circle	652EV/654EV 654EVF/702EV_ 704EV_ /S70-EV_	809043
1	490091	circuit, 2100 W/1-circle		809396
2	490080	circuit, 2400 W/2-circle	EVC7_	809127
2	490079	circuit, 3400 W/2-circle	EVC7_ /EVC9_	809045



Item	Order	Description	Model	OEM
1	300025	7-position switch, 16A		C00213
2	380015	energy regulator/1-circle		809397
3	380024	energy regulator/2-circle		808046



Item	Order	Description	Model	OEM
1	359142	signal lamp/green		807773
2	359143	signal lamp/yellow		806128
3	359327	residual temperature display, 1 heating element compartment		809398
4	359326	residual temperature display, 4 compartments		809047



Item	Order	Description	Model	OEM
1	110818	knob/seven fast		C99695
2	110817	knob/energy regulator		C98971


Ovens (gas)



Item	Order	Description	Model	OEM
1	105321	burner, 5,8kW		C89436
2	105322	burner, 7kW		C89505
3	105312	burner, 5,8kW		C89435
4	105325	burner, 8kW		C99724




Item	Order	Description	Model	OEM
1	101159	gas thermostat	universal	C00600
2	110812	knob		C99698
3	100046	pilot burner		C00711
4	100005	piezoelectric igniter	ET7_/ET9_	C00069




Item	Order	Description	Model	OEM
1	100164	ignition cable, 1300mm	T65_/T70_	C10259
1	100018	ignition cable, 600mm	ET7_/ET9_	C00171
2	102045	thermocouple, 1500mm	T65_/T76_	C10201
2	102042	thermocouple, 850mm	ET7_/ET9_	C00377

Ovens (electric)




Item	Order	Description	Model	OEM
1	416060	heating element, 2200 W	450x570x370mm	C10192
2	416061	heating element, 3000 W	730x570x370mm	C10193
3	416068	heating element, 2500 W	530x650x370mm	C10194



Item	Order	Description	Model	OEM
1	416069	heating element, 4000 W	880x565x37mm	C10195
2	416074	heating element, 2500 W	540x660x300mm	C00215
3	110814	knob oven	-	C99639




Item	Order	Description	Model	OEM
1	300091	switch, 2pole		C00217
2	550060	retainer		
3	375336	thermostat, 250°C		C00545
4	375119	thermostat/complete		C98972



Item	Order	Description	Model	OEM
1	375337	safety thermostat, 1pole		C00546
2	375338	safety thermostat, 3pole		C00686
3	359142	signal lamp/green		807773
4	359143	signal lamp/yellow		806128

Ovens (mechanical)



Item	Order	Description	Model	OEM
1	690531	hinge/right	450x570x370mm	C00130
2	690532	hinge/left	530x650x370mm	C00131
3	690533	hinge/right	730x570x370mm	C10079
4	690534	hinge/left	880x565x370mm	C10080
5	690535	counter part		C00132



Pos.	Order	Description	Model	OEM
1	900224	door seal	450x570x370mm	C10088
2	900226	door seal	530x570x370mm	C10089
3	900227	door seal	530x650x370mm	C10090
4	900228	door seal	880x565x370mm	C10091
5	900225	door seal	540x660x300mm	C10165

Hot cupboards



Item	Order	Description	Model	OEM
1	601004	fan with transverse flow		827914
2	415115	heating register, 2x1000W		827915
3	301003	rocker switch		818181



Item	Order	Description	Model	OEM
1	390082	thermostat, 90°C		807256
2	110816	knob 90°C		C99704



Item	Order	Description	Model	OEM
1	690521	hinge/upper right		C98975
2	690522	hinge/upper left		C98974
3	690523	hinge/lower		C98973
4	690524	door magnet		C00247


Fry tops (gas)




Item	Order	Description	Model	OEM
1	105320	burner	FT_/SFT_	C89458
2	105324	burner	FT_/SFT_	C89457
3	105327	burner	EFT7_/EFT9_	C99717



Item	Order	Description	Model	OEM
1	101159	gas thermostat	FT_T/SFT_	C00084
2	101086	gas tap	FT_	C00085
3	110812	knob/thermostat	FT___T	C99698
4	110811	knob/gas tap		C99683




Item	Order	Description	Model	OEM
1	100122	pilot burner		C00392
2	100708	electrode		C00172
3	102039	thermocouple, 320mm		C00072
3	102042	thermocouple, 850mm		C00377
4	100005	piezoelectric igniter		C00069



Item	Order	Description	Model	OEM
1	101030	ignition unit		C10167
2	100160	ignition switches		C10250
3	101036	battery holder		C10166
4	100018	ignition cable, 600mm		C00171

E

Fry tops (electric)



Item	Order	Description	Model	OEM
1	416062	heating element, 1000 W		C10199
2	416072	heating element, 1500 W		C00644
3	380082	contactor		C00287
4	300017	main switch, 4-pole		C00690



Item	Order	Description	Model	OEM
1	375232	thermostat, 300°C		C00563
2	375326	safety thermostat, 350°C, 1pole		C00564
3	390141	safety thermostat, 350°C, 3pole		C00098



Item	Order	Description	Model	OEM
1	375336	thermostat, 250°C		C00545
2	375337	safety thermostat, 300°, 1pole		C00546
3	375338	safety thermostat, 300°, 3pole		C00686



Item	Order	Description	Model	OEM
1	359142	signal lamp/green		807773
2	359143	signal lamp/yellow		806128
3	110813	knob 0-1		C99707
4	110814	knob 250°C		C99639


Lava rock grills (gas)



Item	Order	Description	Model	OEM
1	105311	burner 7,3kW	PL654	809388
2	105318	burner 7kW	PL702B/ PL704B EGPC7_ _ _	808195
3	105331	burner	EGPL9_ _	808546



Item	Order	Description	Model	OEM
1	101086	gas tap		808196
2	110811	knob	PL_ _ _	C99683
3	100051	pilot burner	EGPL_ _	809197



Item	Order	Description	Model	OEM
1	100005	piezoelectric igniter		C00069
2	100701	electrode	PL_ _ _	807905
3	100019	ignition cable, 1000mm	EGPL_ _	809389
4	102042	thermocouple		C00377

Pasta cookers (gas)




Item	Order	Description	Model	OEM
1	105310	burner		808726
1	105317	burner		808434
2	101086	gas tap		808196
3	110811	knob		C99683
4	100051	pilot burner		808197

Pasta cookers (mechanical)



Item	Order	Description	Model	OEM
1	540700	water inlet	CPG54E,	808037
2	540704	inlet tap	CP704_ ,_	808420
3	540701	inlet tap/handle	CPBM704,	808432
4	540702	drain tap, 3/4"	ECP_ _EB	808433

Bains-marie (gas)




Item	Order	Description	Model	OEM
1	105328	burner		C99711
2	101078	gas thermostat		C00417
3	110812	knob		C99698




Item	Order	Description	Model	OEM
1	100701	electrode		807905
2	100018	ignition cable, 600mm		808230
2	100019	ignition cable, 1000mm		809389
3	100005	piezoelectric igniter		C00069
4	102042	thermocouple, 850mm		C00377
4	102045	thermocouple, 1500mm		C10201

Pasta cookers (electric)



Item	Order	Description	Model	OEM
1	416066	heating element, 1840W/230V		808056
2	416077	heating element, 2520W/230V		808756
3	300002	switch		808052



Item	Order	Description	Model	OEM
1	375021	thermostat, 110°C, 3pole		808058
2	375277	safety thermostat, 160°C		808057
3	110819	knob, 110°C		C99692




Item	Order	Description	Model	OEM
1	359126	insert lamp holder/green		808461
2	359127	insert lamp holder/clear		809085
3	359132	signal element/green, 230V		808943
3	359130	signal element/clear, 230V		809084



Item	Order	Description	Model	OEM
1	100046	pilot burner		C00392
2	100708	electrode		C00172
3	100018	ignition cable, 600mm		C00171
4	100005	piezoelectric igniter, M22		C00069
5	102042	thermocouple, 850mm		C00377

E


Bains-marie (electric)



Item	Order	Description	Model	OEM
1	416067	heating element, 1380 W/230 V	BM652E/654E	808174
2	416071	heating element, 800 W/230 V	CPBM704E	809070
3	416062	heating element, 1000 W/230 V	BM702EB EBM72EB/ 92EB	C10199
4	416072	heating element, 1500 W/230 V	BM704EB EBM92EB/ 94EB	C00644



Item	Order	Description	Model	OEM
1	300074	switch 0-1, 2pole	BM652E/654E	806286
2	300001	switch, 2pole	BM652E/654E CPBM704E	C00217
3	300017	switch 0-I, 4pole	BM702_E/74 SBM_E	C00690
4	300002	switch	EBM_EB	808025



Item	Order	Description	Model	OEM
1	375334	thermostat	BM652E/654E	808144
2	390082	thermostat	BM702_E, SBM_E	807256
3	375021	thermostat	CPBM704E	808058



Item	Order	Description	Model	OEM
1	359132	signal element/green	BM652/BM654	808461
1	359130	signal element/clear	BM652/BM654	809085
2	359126	insert lamp holder/green	BM652/BM654	809943
3	359127	insert lamp holder/clear	BM652/BM654	809084
4	359142	signal lamp/green	BM702E/704E	80773
5	359143	signal lamp/clear	SBM_E/ EBM_EB	806128




Item	Order	Description	Model	OEM
1	380082	contactor	BM702E/704E SBM_E EBM_EB	C00287
2	110813	knob 0-I	BM_E	C99707
3	110816	knob 90°C	SBM_E EBM_EB	C99704


Fryers (gas)




Item	Order	Description	Model	OEM
1	105316	burner/right, 3,8kW		809429
2	105315	burner/left, 3,8kW		809428
3	105314	burner/right, center 4,7kW		808417
4	105313	burner/left, 4,7kW		808419
5	105329	burner/right, 4,7kW		808418



Item	Order	Description	Model	OEM
1	101188	Eurosit controller, 190°C		808934
2	100005	piezoelectric igniter		C00069
3	100018	ignition cable, 600mm		808230
4	100701	electrode		807905




Item	Order	Description	Model	OEM
1	100162	pilot burner		809195
2	100046	pilot burner		C00711
3	102042	thermocouple, 850mm		C00377
4	101265	interrupter		807842
5	375339	safety thermostat		808181




Item	Order	Description	Model	OEM
1	101131	Minisit controller, 190°C		806267
2	101136	piezoelectric igniter		807697
3	100025	ignition cable, 600mm		809439
4	100706	electrode		808177
5	110068	knob		814979


Fryers (electric)



Item	Order	Description	Model	OEM
1	416065	heating element, 1330 W/230 V	FR_ _EGT/	808620
2	416064	heating element, 3300 W/230 V	FR_ _EGM	809460
3	416063	heating element, 6800 W/400 V	FR_ _E/SFR_ _ E1/FR_ _EB1/ EFR_ _EZV	808689
4	416070	heating element, 10200 W/400 V	FR_ _EB/ SFR_ _E1/ EFR_ _ _EB	808256
4	416059	heating element, 15000 W/400 V	EFR9_ _EB	808046



Item	Order	Description	Model	OEM
1	510240	O-ring, 58mm		808054
2	510242	O-ring, 63mm		808055
3	550447	nut, M54x1		808892
4	550448	special hose		808894




Item	Order	Description	Model	OEM
1	375261	thermostat, 95-190°C 1-pole		808935
2	375260	safety thermostat, 240° 1-pole		808430
3	375410	thermostat, 90-180°C 3-pole		807603
4	375258	safety thermostat, 225° 3-pole		807349



Item	Order	Description	Model	OEM
1	300002	switch, 4-pole		808052
2	375261	thermostat, 95-190°C 1-pole		808935
3	375258	safety thermostat, 225° 3-pole		807349



Item	Order	Description	Model	OEM
1	359126	insert lamp holder/green		808461
2	359127	insert lamp holder/clear		809085
3	359132	signal element/green, 230V		808943
3	359130	signal element/clear, 230V		809084



Item	Order	Description	Model	OEM
1	380244	contactor, 25A		807553
2	300128	micro switch		808053
3	110815	knob, 200°C		C99686

Tilting bratt pans (gas)




Item	Order	Description	Model	OEM
1	101126	Elettrosit gas valve, 1/2"	EBRG_ _	C00302
2	101312	micro switch	EBRG_ _	C00309
3	100122	pilot burner	EBRG_ _	C00392




Item	Order	Description	Model	OEM
1	101030	ignition unit, 1,5V	EBRG_ _	C10167
2	100018	ignition cable, 600mm	EBRG_ _	C00171
3	100708	electrode	EBRG_ _	C00172
4	102042	thermocouple, 850mm	EBRG_ _	C00377


Tilting bratt pans (electric)



Item	Order	Description	Model	OEM
1	416075	heating element, 1200W	EBRE_1200W	C00650
2	380261	contactor	EBRE_24V	C00571 828253



Item	Order	Description	Model	OEM
1	400202	p.c.b. board, 24V		C00566
2	400203	transformer, 240V/24V		C00506
3	300136	rocker switch, 24V	EBRG_24V	C00610
4	359129	signal element, 24V		C00614
5	359124	insert lamp holder/yellow		



Item	Order	Description	Model	OEM
1	375232	thermostat, 300°C		C00563
2	390141	safety thermostat	EBRG_250°C	C00098
3	110814	knob, 250°C	EBRE_250°C	C99639




Item	Order	Description	Model	OEM
1	300137	limit switch		C00430
2	345412	contactor block	EBRGA_24V	C00279
3	300134	push button	EBREA_24V	C00278


Boiling pans (gas)



Item	Order	Description	Model	OEM
1	105319	burner	PG_105319	809467
2	105330	burner	EPG9_105330	808738



Item	Order	Description	Model	OEM
1	100050	pilot burner	PG7050/EPG750	809474
2	100148	pilot burner	EPG9100 - 9150	808524
3	100701	electrode		809475
4	100009	piezoelectric igniter	PG750/EPG750	809476
5	100147	ignition cable	EPG9100 - 9150	809468




Item	Order	Description	Model	OEM
1	101341	gas tap PEL22	PG7050/EPG750	809469
2	101092	gas tap PEL23	EPG9100 - 9150	808520
3	102077	thermocouple, 1500mm	PG7050/EPG750	808521
4	110811	knob	EPG9100 - 9150	C99683



Item	Order	Description	Model	OEM
1	101914	Novasit gas valve		808578
2	102317	ignition control module	PG7050 I/EPG750 I	808762
3	100756	monitoring electrode	EPG9100 I - 9150 I	808593
4	100755	ignition electrode		808592

Boiling pans (mechanical)



Item	Order	Description	Model	OEM
1	541025	pressure switch		808590
2	375341	thermostat	PG7050 I/EPG750 I	809036
3	375281	safety thermostat	EPG9100 I - 9150 I	808203
4	110819	knob 110°C		C99692




Item	Order	Description	Model	OEM
1	300131	push button complete		809472
2	300132	switch complete	PG7050 I/EPG750 I	808641
3	359291	signal lamp	EPG9100 I - 9150 I	809133

Boiling pans (electric)



Item	Order	Description	Model	OEM
1	416073	heating element, 6000W	PE7050 I/PE750 I PE9100 I - 9150 I	808525
2	416078	heating element, 8000W	PE9100 I - 9150 I	808595
3	521118	gasket 2"	PE7050 I/PE750 I PE9100 I - 9150 I	808594



Item	Order	Description	Model	OEM
1	541025	pressure switch		808590
2	375341	thermostat	PE7050 I/PE750 I	809036
3	375281	safety thermostat	PE9100 I - 9150 I	808203
4	110819	knob 110°C		C99692



Item	Order	Description	Model	OEM
1	300132	switch/complete		808641
2	359291	signal lamp, 230V	PE7050 I/PE750 I PE9100 I - 9150 I	809133
3	380082	contactor		C00287



Item	Order	Description	Model	OEM
1	540131	drain cock, 1 1/4"	P_7050 I/P_7050 I EP_750/EP_750 I	808350
1	540134	drain cock, 2"	EP_9100 - 9150 EP_9100 I - 9150 I	806172
2	540202	inspection glass	P_7050 I/P_7050 I EP_750/EP_750 I	808704
3	540707	fitting complete		809473



Item	Order	Description	Model	OEM
1	540827	pressure relief valve		809385
2	541062	manometer	P_7050 I/P_7050 I EP_750/EP_750 I	808347
3	540705	inlet pipe		809314