



# *Spare parts suitable for:* **ROLLERGRILL**



## Toasters



| Item | Order  | Description  | Model              | OEM    |
|------|--------|--------------|--------------------|--------|
| 1    | 416760 | quartz tube  | BAR100/106/200/206 | DO4005 |
| 2    | 416761 | heating coil | BAR100/200         | DO1003 |
| 3    | 416762 | heating coil | BAR106/206         | DO1043 |



| Item | Order  | Description  | Model   | OEM    |
|------|--------|--------------|---------|--------|
| 1    | 416763 | quartz tube  | RST127, | DO4009 |
| 2    | 416764 | heating coil | RST227  | DO1035 |
| 3    | 416765 | quartz tube  | RST128, | DO4010 |
| 4    | 416766 | heating coil | RST228  | DO1036 |




| Item | Order  | Description | Model       | OEM    |
|------|--------|-------------|-------------|--------|
| 1    | 300094 | switch      | BAR100/200, | A01001 |
| 2    | 360164 | timer       | BAR106/206, | A02008 |
| 3    | 110650 | knob        | RST127/227, | A14042 |
| 4    | 359900 | signal lamp | RST128/228  | A08005 |




| Item | Order  | Description | Model                             | OEM    |
|------|--------|-------------|-----------------------------------|--------|
| 1    | 693035 | handle      | BAR100/200,<br>RST127/128/227/228 | F01025 |
| 2    | 693036 | handle      | BAR106/206                        | A15033 |


## Conveyor belt toasters



| Item | Order  | Description     | Model | OEM    |
|------|--------|-----------------|-------|--------|
| 1    | 416709 | quartz tube     | CT540 | DO4015 |
| 2    | 416714 | heating (upper) |       | DO1040 |
| 3    | 416710 | heating (lower) |       | DO1041 |




| Item | Order  | Description   | Model | OEM    |
|------|--------|---------------|-------|--------|
| 1    | 300094 | switch        | CT540 | A01001 |
| 2    | 300144 | potentiometer |       | A04005 |
| 3    | 110651 | knob          |       | A14078 |




| Item | Order  | Description | Model | OEM    |
|------|--------|-------------|-------|--------|
| 1    | 500604 | motor       | CT540 | A03036 |
| 2    | 359288 | signal lamp |       | A08011 |
| 3    | 359900 | signal lamp |       | A08005 |

## Folding grills/waffle iron




| Item | Order  | Description       | Model      | OEM    |
|------|--------|-------------------|------------|--------|
| 1    | 416722 | 750W/230V         | GES_, GED_ | D02140 |
| 2    | 416724 | 1200W/230 (lower) | Majestic   | D02112 |
| 3    | 416723 | 800W/230V (upper) | Savoye     | D02113 |




| Item | Order  | Description        | Model         | OEM    |
|------|--------|--------------------|---------------|--------|
| 1    | 416701 | 1800W/230V (lower) | Panini,       | D02115 |
| 2    | 416725 | 1200W/230V (upper) | Double Panini | D02114 |



| Item | Order  | Description             | Model                    | OEM    |
|------|--------|-------------------------|--------------------------|--------|
| 1    | 301010 | switch                  | GES_, GED_               | A07012 |
| 2    | 301202 | switch                  | Majestic, Savoye, Panini | A07030 |
| 3    | 550457 | connector block, 2 pole | universal                | A16012 |
| 4    | 550411 | connector block, 6 pole |                          | A16014 |



| Item | Order  | Description          | Model             | OEM    |
|------|--------|----------------------|-------------------|--------|
| 1    | 375134 | thermostat, 40-280°C | GES_, GED_,       | A06032 |
| 2    | 110651 | knob                 | Majestic, Savoye, | A14078 |
| 3    | 359900 | signal lamp, 230V    | Panini, Double    | A08005 |
| 4    | 359288 | signal lamp, 230V    | Panini            | A08011 |




| Item | Order  | Description       | Model                                   | OEM    |
|------|--------|-------------------|-----------------------------------------|--------|
| 1    | 693019 | spring            | Majestic, Panini, Double Panini, Savoye | B07015 |
| 2    | 693042 | protection spring | universal                               | C04005 |
| 3    | 693161 | handle            | Majestic                                | A15036 |



| Item | Order  | Description | Model        | OEM                  |
|------|--------|-------------|--------------|----------------------|
| 1    | 693348 | plate/upper | GES10, GED10 | B02029SUO            |
| 2    | 693349 | plate/lower |              | B02029INF            |
| 3    | 693350 | plate/upper | GES20, GED20 | B02028UP, B02032UP   |
| 4    | 693351 | plate/lower |              | B02028INF, B02032INF |




| Item | Order  | Description | Model        | OEM       |
|------|--------|-------------|--------------|-----------|
| 1    | 693352 | plate/upper | GES30, GED30 | B02030UP  |
| 2    | 693353 | plate/lower |              | B02030INF |
| 3    | 693354 | plate/upper | GES40, GED40 | B02031UP  |
| 4    | 693355 | plate/lower |              | B02031INF |



| Item | Order  | Description         | Model  | OEM    |
|------|--------|---------------------|--------|--------|
| 1    | 693356 | plate/upper, plane  | Panini | B02033 |
| 2    | 693357 | plate/lower, plane  |        | B02025 |
| 3    | 693358 | plate/upper, fluted |        | B02024 |
| 4    | 693359 | plate/lower, fluted |        | B02023 |



| Item | Order  | Description         | Model    | OEM    |
|------|--------|---------------------|----------|--------|
| 1    | 693360 | plate/lower plane   | Majestic | B02031 |
| 2    | 693363 | plate/lower fluted  |          | B02017 |
| 3    | 693362 | plate/lower 1/2-1/2 |          | B02022 |




| Item | Order  | Description        | Model            | OEM    |
|------|--------|--------------------|------------------|--------|
| 1    | 693364 | plate/upper plane  | Majestic, Savoye | B02034 |
| 2    | 693365 | plate/upper fluted |                  | B02019 |
| 3    | 693366 | plate/lower plane  | Savoye           | B02020 |
| 4    | 693367 | plate/lower fluted |                  | B02018 |

## Fry tops (gas)




| Item | Order  | Description | Model   | OEM    |
|------|--------|-------------|---------|--------|
| 1    | 105505 | burner      |         | E01006 |
| 2    | 101491 | gas tap     |         | E02030 |
| 3    | 110655 | knob        | PSG400, | A14077 |
| 4    | 100984 | jet 75      | PSG600  | E02074 |
| 4    | 100985 | jet 85      |         | E02075 |
| 4    | 100986 | jet 125     |         | E02102 |


## Fry tops (electric)



| Item | Order  | Description        | Model   | OEM    |
|------|--------|--------------------|---------|--------|
| 1    | 416748 | 2000 W/230 V       | PSE400  | D02102 |
| 2    | 416749 | 1750 W/230 V       | PSE600  | D02081 |
| 2    | 416700 | 3000 W/230 V       | PSE600  | D02141 |
| 3    | 301202 | switch             |         | A07030 |
| 4    | 359900 | signal lamp, 230 V | PSE400, | A8005  |
| 5    | 359288 | signal lamp, 230 V | PSE600  | A8011  |



| Item | Order  | Description | Model   | OEM            |
|------|--------|-------------|---------|----------------|
| 1    | 375505 | thermostat  | PSE400, | A06003, A06042 |
| 2    | 110651 | knob        | PSE600  | A14078         |




| Item | Order  | Description | Model          | OEM    |
|------|--------|-------------|----------------|--------|
| 1    | 693361 | plate       | PSG400, PSE400 | B02027 |
| 2    | 693015 | plate       | PSG600, PSE600 | B02026 |

## Crepes makers (gas)




| Item | Order  | Description    | Model                   | OEM       |
|------|--------|----------------|-------------------------|-----------|
| 1    | 693021 | plate 350      | 350G/GD                 | B02016    |
| 2    | 693020 | plate 400      | 400G/GD, 400FG          | B02015    |
| 3    | 105501 | flame spreader | 350G/GD, 400G/GD, 400FG | 68009I110 |




| Item | Order  | Description | Model | OEM    |
|------|--------|-------------|-------|--------|
| 1    | 105500 | burner      |       | E01003 |
| 2    | 100984 | jet 75      | 400G  | E02074 |
| 2    | 100985 | jet 85      | 350GD | E02075 |
| 2    | 100988 | jet 135     | 400GD | E02076 |
| 3    | 101094 | gas tap     |       | E02036 |
| 4    | 110651 | knob        |       | A14076 |


## Crepes makers (electric)



| Item | Order  | Description | Model              | OEM    |
|------|--------|-------------|--------------------|--------|
| 1    | 693021 | plate 350   | 350E, 350GD        | B02016 |
| 2    | 693020 | plate 400   | 400E, 400ED, 400FE | B02015 |




| Item | Order  | Description  | Model            | OEM    |
|------|--------|--------------|------------------|--------|
| 1    | 416726 | 3000 W/230 V | 350E/ED, 400E/ED | D02013 |
| 2    | 416771 | 3600 W/230 V | 400FE            | D02022 |



| Item | Order  | Description       | Model              | OEM    |
|------|--------|-------------------|--------------------|--------|
| 1    | 375505 | thermostat        |                    | A06042 |
| 2    | 110651 | knob              | 350E, 350ED, 400E, | A14078 |
| 3    | 359900 | signal lamp, 230V | 400ED, 400FE       | A08005 |

### Lava rock grills (electrical)




| Item | Order  | Description      | Model     | OEM    |
|------|--------|------------------|-----------|--------|
| 1    | 416772 | 2500W/230V       |           | D02011 |
| 2    | 380015 | energy regulator | 140, 140D | A04006 |
| 3    | 110650 | knob             |           | A14042 |
| 4    | 359900 | signal lamp      |           | A08005 |

### Roller grills




| Item | Order  | Description           | Model               | OEM    |
|------|--------|-----------------------|---------------------|--------|
| 1    | 693032 | CNS-pipe with impulse |                     | B04072 |
| 2    | 416755 | 125W/230V             |                     | D02037 |
| 3    | 416716 | steatite bush         | RG5, RG7, RG9, RG11 | A09003 |
| 4    | 693038 | teflon ring           |                     | B06029 |
| 5    | 693031 | chain                 |                     | B07020 |
| 6    | 500603 | motor                 |                     | A03038 |




| Item | Order  | Description      | Model               | OEM    |
|------|--------|------------------|---------------------|--------|
| 1    | 380015 | energy regulator |                     | A04006 |
| 2    | 110651 | knob             | RG5, RG7, RG9, RG11 | A14078 |
| 3    | 301202 | switch           |                     | A07027 |
| 4    | 359900 | signal lamp      |                     | A08005 |

### Gyros grills (gas)



| Item | Order  | Description | Model       | OEM        |
|------|--------|-------------|-------------|------------|
| 1    | 105509 | burner      | GRG40/60/80 | E01005     |
| 2    | 105508 | grid        | GRG40/80    | 36063Grill |
| 3    | 105511 | grid        | GRG60       | 36065Grill |




| Item | Order  | Description          | Model               | OEM    |
|------|--------|----------------------|---------------------|--------|
| 1    | 105510 | jet                  |                     | B04011 |
| 2    | 101491 | gas tap              | GRG40, GRG60, GRG80 | E02030 |
| 3    | 110656 | knob                 |                     | A14075 |
| 4    | 102064 | thermocouple, 1000mm |                     | E02029 |

### Gyros grills (electrical)



| Item | Order  | Description    | Model               | OEM    |
|------|--------|----------------|---------------------|--------|
| 1    | 416704 | 2500W/230V     |                     | D02075 |
| 2    | 301200 | switch         | GRE40, GRE60, GRE80 | A07002 |
| 3    | 359900 | signal lamp    |                     | A08005 |
| 4    | 550413 | terminal board |                     | A16010 |
| 5    | 300094 | switch         |                     | A01001 |
| 6    | 110651 | knob           |                     | A14078 |


### Gyros grills (mechanical)




| Item | Order  | Description | Model               | OEM    |
|------|--------|-------------|---------------------|--------|
| 1    | 693008 | skewer      | GR_40               | F03028 |
| 2    | 693033 | skewer      | GR_60               | F03029 |
| 3    | 693034 | skewer      | GR_80               | F03030 |
| 4    | 500600 | motor       | GR_40, GR_60, GR_80 | A03025 |

R

## Salamander (gas)




| Item | Order  | Description    | Model        | OEM    |
|------|--------|----------------|--------------|--------|
| 1    | 105507 | burner         | SGM60        | E01001 |
| 2    | 105506 | burner         | SGF80        | E01002 |
| 3    | 250008 | gas line (CNS) | SGM60        | E02087 |
| 4    | 105512 | gas line (CNS) |              | E02088 |
| 5    | 101397 | gas tap        | SGM60, SGF80 | E02031 |
| 6    | 110652 | knob           |              | A14076 |




| Item | Order  | Description          | Model | OEM    |
|------|--------|----------------------|-------|--------|
| 1    | 100043 | pilot burner         |       | E02032 |
| 2    | 102064 | thermocouple, 1000mm |       | E02029 |
| 3    | 100982 | main jet 85          |       | E02077 |
| 3    | 100983 | main jet 100         |       | E02090 |
| 3    | 100987 | main jet 130         |       | E02079 |
| 4    | 100245 | pilot Venturi 0,20   |       | E02086 |
| 5    | 100246 | pilot Venturi 0,35   |       | E02086 |


## Salamander (electric)



| Item | Order  | Description                 | Model | OEM    |
|------|--------|-----------------------------|-------|--------|
| 1    | 416756 | 950W/230V                   | SEM60 | D02091 |
| 2    | 416715 | quartz tube                 |       | D04007 |
| 3    | 416708 | 950W/230V                   |       | D01032 |
| 4    | 416716 | steatite bush               |       | A09003 |
| 5    | 693041 | insulating mat, 315 x 195mm |       | A02002 |




| Item | Order  | Description   | Model | OEM    |
|------|--------|---------------|-------|--------|
| 1    | 416759 | 730W/230V     | SEF80 | D02092 |
| 2    | 416757 | quartz tube   |       | D04006 |
| 3    | 416758 | 550W/230V     |       | D01031 |
| 4    | 416716 | steatite bush |       | A09003 |




| Item | Order  | Description     | Model        | OEM    |
|------|--------|-----------------|--------------|--------|
| 1    | 359900 | signal lamp     | SEM60, SEF80 | A08005 |
| 2    | 300094 | selector switch |              | A01001 |
| 3    | 110651 | knob            |              | A14078 |

## Rotisseries grill (gas)



| Item | Order  | Description  | Model             | OEM    |
|------|--------|--------------|-------------------|--------|
| 1    | 105506 | burner       | RGB4, RGB8, RGB12 | E01002 |
| 2    | 102041 | thermocouple |                   | E02033 |
| 3    | 102241 | thermocouple |                   | E02030 |
| 4    | 101491 | gas tap      |                   | E02030 |
| 5    | 110652 | knob         |                   | A14076 |

## Rotisserie grills (electrical)




| Item | Order  | Description     | Model             | OEM    |
|------|--------|-----------------|-------------------|--------|
| 1    | 416702 | 1100W/230V      | RBE4, RBE8, RBE12 | D02068 |
| 2    | 416751 | quartz tube     |                   | D04003 |
| 3    | 416750 | 1100W/230V      |                   | D01033 |
| 4    | 300094 | selector switch |                   | A01001 |
| 5    | 110651 | knob            |                   | A14078 |


## Rotisseries grill (gas/electric)




| Item | Order  | Description    | Model      | OEM    |
|------|--------|----------------|------------|--------|
| 1    | 301200 | switch         | RRB_4/8/12 | A07002 |
| 2    | 301001 | switch         | RGB4/8/12  | A07003 |
| 3    | 359712 | bulb + housing | RB_4/8/12  | A18005 |
| 4    | 359900 | signal lamp    |            | A08005 |
| 5    | 550459 | terminal board | RBE4/8/12  | A16004 |




| Item | Order  | Description     | Model | OEM    |
|------|--------|-----------------|-------|--------|
| 1    | 301202 | switch          | RBE25 | A07030 |
| 2    | 359043 | signal lamp     |       | A08008 |
| 3    | 345320 | selector switch |       | A01009 |
| 4    | 110651 | knob            |       | A14078 |



| Item | Order  | Description      | Model       | OEM    |
|------|--------|------------------|-------------|--------|
| 1    | 693010 | skewer           | RBE4, RGB4, | F03019 |
| 2    | 693012 | end clamp        | RBE8, RGB8, | F03021 |
| 3    | 693011 | ignition bracket | RBE12,      | F03020 |
| 4    | 500601 | motor            | RBG12       | A03008 |



| Item | Order  | Description | Model | OEM            |
|------|--------|-------------|-------|----------------|
| 1    | 350043 | timer       | RBE25 | A02010         |
| 2    | 110651 | knob        |       | A14078         |
| 3    | 375505 | thermostat  |       | A06020, A06006 |
| 4    | 110651 | knob        |       | A14078         |



| Item | Order  | Description      | Model | OEM    |
|------|--------|------------------|-------|--------|
| 1    | 416705 | heating element  | RBE25 | D02074 |
| 2    | 416753 | quartz tube      |       | D04011 |
| 3    | 416752 | heating coil     |       | D01030 |
| 4    | 416716 | sealant          |       | A09003 |
| 5    | 359735 | bulb lamp holder |       | A18011 |
| 6    | 359647 | halogen lamp     |       | A18003 |


## Hot-air ovens



| Item | Order  | Description | Model              | OEM    |
|------|--------|-------------|--------------------|--------|
| 1    | 416731 | 1500W/230V  | FC26, TH1          | D02052 |
| 2    | 416730 | 2500W/230V  | Classic Noir, FC33 | D02143 |
| 3    | 416734 | 2500W/230V  | FC34               | D02086 |




| Item | Order  | Description | Model         | OEM    |
|------|--------|-------------|---------------|--------|
| 1    | 416773 | 3000W/230V  | FC60, FC60G   | D02034 |
| 2    | 416774 | 5000W/230V  | FC110, FC110G | D02045 |




| Item | Order  | Description | Model | OEM              |
|------|--------|-------------|-------|------------------|
| 1    | 380238 | contactor   | RBE25 | A05002<br>A05006 |
| 2    | 541085 | thermometer |       | A18007           |
| 3    | 693030 | drive chain |       | B07013           |
| 4    | 500602 | motor       |       | A03007           |

R


Suitable for Rollergrill




| Item | Order  | Description            | Model  | OEM           |
|------|--------|------------------------|--------|---------------|
| 1    | 416733 | quartz heating element | FC33   | D04001+D01037 |
| 2    | 416914 | quartz heating element | FC60G  | D04028, D4020 |
| 3    | 416776 | quartz heating element | FC110G | D04025        |



| Item | Order  | Description | Model                                    | OEM            |
|------|--------|-------------|------------------------------------------|----------------|
| 1    | 375505 | thermostat  | FC26/33/34/60/60G/110/110G, Classic Noir | A06006, A06042 |
| 2    | 375155 | thermostat  | THA                                      | A06019         |
| 3    | 360097 | timer       | FC26/33/34, Classic Noir                 | A02015         |




| Item | Order  | Description     | Model                | OEM    |
|------|--------|-----------------|----------------------|--------|
| 1    | 360327 | timer           | FC60/60G, FC110/110G | A02014 |
| 2    | 350043 | timer           | TH1                  | A02010 |
| 3    | 300142 | selector switch | FC60G                | A01006 |
| 4    | 300143 | selector switch | FC110G               | A01014 |



| Item | Order  | Description | Model                      | OEM    |
|------|--------|-------------|----------------------------|--------|
| 1    | 110654 | knob        | Classic Noir               | A14090 |
| 2    | 110650 | knob        | FC26                       | A14042 |
| 3    | 110651 | knob        | FC33/34/60/60G, FC110/110G | A14078 |
| 4    | 110563 | knob        | TH1                        | A14029 |



| Item | Order  | Description        | Model         | OEM    |
|------|--------|--------------------|---------------|--------|
| 1    | 359900 | signal lamp, 230 V | FC26, FC34    | A08005 |
| 2    | 359288 | signal lamp, 230 V |               | A08011 |
| 3    | 359042 | signal lamp, 230 V | FC33, FC60,   | A08003 |
| 4    | 359043 | signal lamp, 230 V | FC60G, FC110, | A08008 |
| 5    | 359041 | signal lamp, 230 V | FC110G        | A08009 |



| Item | Order  | Description  | Model         | OEM    |
|------|--------|--------------|---------------|--------|
| 1    | 345062 | micro switch | FC33          | A07023 |
| 2    | 345699 | micro switch | FC110, FC110G | A07017 |
| 3    | 301099 | switch       | FC110, F110G  | A07015 |
| 4    | 301004 | switch       | FC33          | A07022 |
| 5    | 301066 | switch       | TH1           | A07005 |




| Item | Order  | Description        | Model       | OEM    |
|------|--------|--------------------|-------------|--------|
| 1    | 359718 | bulb + housing     | FC60, FC60G | A18004 |
| 2    | 390503 | safety thermostat  | FC110,      | A06034 |
| 3    | 390504 | thermostat (steam) | FC110G      | A06048 |




| Item | Order  | Description    | Model         | OEM    |
|------|--------|----------------|---------------|--------|
| 1    | 370216 | solenoid valve |               | B10006 |
| 2    | 380213 | contactor      | FC110, FC110G | A05008 |
| 3    | 550411 | terminal board |               | A16014 |




| Item | Order  | Description | Model                         | OEM    |
|------|--------|-------------|-------------------------------|--------|
| 1    | 601017 | motor       | FC26/33/34, TH1, Classic Noir | A03006 |
| 1    | 601118 | fan wheel   | FC60/60G                      | A03001 |
| 2    | 601122 | fan         | FC110/110G                    | A03010 |



| Item | Order  | Description | Model              | OEM    |
|------|--------|-------------|--------------------|--------|
| 1    | 900240 | door seal   | FC26               | H03002 |
| 2    | 900241 | door seal   | FC33, Classic Noir | H03010 |



| Item | Order  | Description | Model         | OEM    |
|------|--------|-------------|---------------|--------|
| 1    | 900243 | door seal   | FC60, FC60G   | H03005 |
| 2    | 900244 | door seal   | FC110, FC110G | H03006 |




| Item | Order  | Description | Model                          | OEM    |
|------|--------|-------------|--------------------------------|--------|
| 1    | 693024 | spring      | Classic Noir, FC26, FC33, FC34 | B07002 |
| 2    | 693043 | door rod    | FC26, FC34                     | F02005 |
| 3    | 693023 | hinge       | Classic Noir, FC33             | H04096 |



| Item | Order  | Description  | Model         | OEM    |
|------|--------|--------------|---------------|--------|
| 1    | 693044 | hinge        | FC60, FC60G,  | B09005 |
| 2    | 693045 | body section | FC110, FC110G | B09007 |

## Pizza ovens




| Item | Order  | Description          | Model | OEM    |
|------|--------|----------------------|-------|--------|
| 1    | 416707 | quartz tube          |       | D04012 |
| 2    | 416711 | heating coil (upper) | PZ330 | D01024 |
| 3    | 416706 | heating coil (lower) |       | D01025 |
| 4    | 416736 | quartz tube          |       | D04013 |
| 5    | 416737 | heating coil (upper) | PZ660 | D01026 |
| 6    | 416738 | heating coil (lower) |       | D01027 |




| Item | Order  | Description       | Model        | OEM    |
|------|--------|-------------------|--------------|--------|
| 1    | 301010 | switch            |              | A07012 |
| 2    | 359900 | signal lamp, 230V | PZ330, PE660 | A08005 |
| 3    | 359288 | signal lamp, 230V |              | A08011 |




| Item | Order  | Description | Model  | OEM    |
|------|--------|-------------|--------|--------|
| 1    | 375505 | thermostat  |        | A06042 |
| 2    | 110651 | knob        | PZ330, | A14078 |
| 3    | 360096 | timer       | PE660  | A02013 |
| 4    | 110651 | knob        |        | A14078 |




| Item | Order  | Description    | Model | OEM    |
|------|--------|----------------|-------|--------|
| 1    | 693009 | fireclay plate | PZ330 | F07008 |
| 2    | 693001 | fireclay plate | PZ660 | F07005 |



| Item | Order  | Description | Model | OEM    |
|------|--------|-------------|-------|--------|
| 1    | 416727 | 650 W/230 V | PZ400 | D02148 |
| 2    | 301010 | switch      |       | A07012 |
| 3    | 359900 | signal lamp |       | A08005 |
| 4    | 693036 | handle      |       | A15033 |



| Item | Order  | Description      | Model                 | OEM    |
|------|--------|------------------|-----------------------|--------|
| 1    | 380015 | energy regulator | CSOE, CS3E, CS4E, HD4 | A04006 |
| 2    | 110650 | knob             |                       | A14042 |
| 3    | 359900 | signal lamp      |                       | A08005 |
| 4    | 110921 | handle           |                       | A15001 |



| Item | Order  | Description | Model | OEM    |
|------|--------|-------------|-------|--------|
| 1    | 375505 | thermostat  | PZ400 | A06042 |
| 2    | 110651 | knob        |       | A14078 |
| 3    | 360098 | timer       |       | A02016 |
| 4    | 110651 | knob        |       | A14078 |




| Item | Order  | Description | Model            | OEM    |
|------|--------|-------------|------------------|--------|
| 1    | 693005 | tub         | CS0E, CS4E, CS3E | F05022 |
| 2    | 693006 | tub (CNS)   |                  | F05025 |
| 3    | 693002 | glass       |                  | F05009 |
| 4    | 693003 | plastic     |                  | F05012 |

## Smokers

no picture

1



2



3

| Item | Order  | Description | Model    | OEM    |
|------|--------|-------------|----------|--------|
| 1    | 416747 | 250 W/230 V | FM2, FM3 | D02053 |
| 2    | 360096 | timer 15'   |          | A02001 |
| 3    | 110650 | knob        |          | A14042 |




| Item | Order  | Description | Model            | OEM    |
|------|--------|-------------|------------------|--------|
| 1    | 693004 | basket      | CS0E, CS4E, CS3E | F04012 |
| 2    | 693051 | lid         |                  | F05038 |
| 3    | 110920 | button      |                  | A17001 |

## Hot dog machines




| Item | Order  | Description      | Model            | OEM    |
|------|--------|------------------|------------------|--------|
| 1    | 416703 | 650 W/230 V      | CS0E, CS4E, CS3E | D02001 |
| 2    | 416718 | 500 W/230 V      | HD4              | D02002 |
| 3    | 693018 | aluminium skewer | CSBE, CS4E, HD4  | F05010 |

## Heater




| Item | Order  | Description         | Model        | OEM    |
|------|--------|---------------------|--------------|--------|
| 1    | 416717 | 650 W/230 V         | DW106        | D02004 |
| 2    | 416712 | 1300 W/230 V        | DW110        | D02003 |
| 3    | 416720 | hot plate           | DW10G, DW110 | F03003 |
| 4    | 693014 | insulating covering |              | F07009 |




| Item | Order  | Description       | Model           | OEM    |
|------|--------|-------------------|-----------------|--------|
| 1    | 375177 | thermostat        | DW106,<br>DW110 | A06018 |
| 2    | 110650 | knob              |                 | A14042 |
| 3    | 359900 | signal lamp, 230V |                 | A08005 |

### Hot cupboards




| Item | Order  | Description | Model         | OEM    |
|------|--------|-------------|---------------|--------|
| 1    | 416719 | 600W/230V   | Auberge relay | D02014 |
| 2    | 375005 | thermostat  |               | A06041 |
| 3    | 110650 | knob        |               | A14042 |
| 4    | 359900 | signal lamp |               | A08005 |

### Food warmers




| Item | Order  | Description | Model | OEM    |
|------|--------|-------------|-------|--------|
| 1    | 416715 | quartz tube | H1    | D04007 |
| 2    | 416729 | 600W/230V   |       | D01021 |
| 3    | 693022 | steatite    |       | A09001 |
| 4    | 301202 | switch      |       | A07020 |


### Bains-marie



| Item | Order  | Description | Model          | OEM    |
|------|--------|-------------|----------------|--------|
| 1    | 416777 | 500W/230V   | BMS, BM3       | D02029 |
| 2    | 416778 | 1500W/230V  | BMSECO, BMGECO | D02073 |
| 3    | 416779 | 1750W/230V  | BMD            | D02101 |



| Item | Order  | Description     | Model          | OEM    |
|------|--------|-----------------|----------------|--------|
| 1    | 301202 | rocker switch   | BMSECO, BMGECO | A07027 |
| 2    | 301003 | rocker switch   | BMD            | A07032 |
| 3    | 359900 | signal lamp     | BMS, BM3, BMD  | A08005 |
| 4    | 300094 | selector switch | BMS, BM3       | A01001 |
| 5    | 110653 | knob            |                | A14029 |




| Item | Order  | Description | Model                            | OEM    |
|------|--------|-------------|----------------------------------|--------|
| 1    | 375400 | thermostat  | BMS, BM3, BMD,<br>BMSECO, BMGECO | A06021 |
| 2    | 110650 | knob        | BMSECO, BMGECO                   | A14042 |
| 3    | 110657 | knob        | BMD                              | A14084 |
| 4    | 110653 | knob        | BMS, BM3                         | A14029 |



| Item | Order  | Description         | Model       | OEM    |
|------|--------|---------------------|-------------|--------|
| 1    | 693046 | drain tap, complete | BMS, BM3    | B10001 |
| 2    | 693040 | drain tap           | BMD, BMGECO | B10004 |


### Pasta cookers



| Item | Order  | Description | Model | OEM            |
|------|--------|-------------|-------|----------------|
| 1    | 416728 | 2200W/230V  | CP60  | D02084         |
| 2    | 301200 | switch      |       | A07002         |
| 3    | 375505 | thermostat  |       | A06022, A06044 |
| 4    | 110653 | knob        |       | A14029         |
| 5    | 693040 | drain tap   |       | B10004         |

R


## Steam cookers



| Item | Order  | Description        | Model | OEM    |
|------|--------|--------------------|-------|--------|
| 1    | 416780 | 2000 W/230 V       | CV23  | D02012 |
| 2    | 359288 | signal lamp, 230 V |       | A08011 |
| 3    | 359900 | signal lamp, 230 V |       | A08005 |



| Item | Order  | Description | Model             | OEM    |
|------|--------|-------------|-------------------|--------|
| 1    | 359736 | lamp holder | WDL100, WDL200, V | A18014 |
| 2    | 359737 | lamp        | HC1000            | A18013 |




| Item | Order  | Description | Model | OEM    |
|------|--------|-------------|-------|--------|
| 1    | 375007 | thermostat  | CV23  | A06044 |
| 2    | 110650 | knob        |       | A14042 |
| 3    | 360151 | timer       |       | A02012 |
| 4    | 110650 | knob        |       | A14042 |




| Item | Order  | Description  | Model   | OEM     |
|------|--------|--------------|---------|---------|
| 1    | 601017 | motor        | VHC1000 | A03006  |
| 2    | 416730 | 2500 W/230 V |         | D02143  |
| 3    | 541063 | thermometer  |         | SA18010 |

## Egg cookers




| Item | Order  | Description  | Model | OEM    |
|------|--------|--------------|-------|--------|
| 1    | 416744 | 2000 W/230 V | C06   | D02010 |
| 2    | 375400 | thermostat   |       | A06021 |
| 3    | 110653 | knob         |       | A14029 |
| 4    | 359900 | signal lamp  |       | A08005 |




| Item | Order  | Description | Model   | OEM    |
|------|--------|-------------|---------|--------|
| 1    | 301202 | switch      | VHC1000 | A07027 |
| 2    | 375505 | thermostat  |         | A06042 |
| 3    | 110650 | knob        |         | A14042 |

## Hot display cabinets




| Item | Order  | Description        | Model                            | OEM    |
|------|--------|--------------------|----------------------------------|--------|
| 1    | 416703 | 650 W/230 V        | WD100, WD200, W<br>DL100, WDL200 | D02001 |
| 2    | 301010 | switch             |                                  | A07012 |
| 3    | 359900 | signal lamp, 230 V |                                  | A08005 |
| 4    | 375505 | thermostat         |                                  | A06041 |
| 5    | 110650 | knob               |                                  | A14042 |


## Fryers




| Item | Order  | Description  | Model        | OEM    |
|------|--------|--------------|--------------|--------|
| 1    | 416743 | 2000 W/230 V | RF3S         | D02018 |
| 2    | 416744 | 2000 W/230 V | RFS, RFDs    | D02010 |
| 3    | 416745 | 2500 W/230 V | RF5SP, RFDSP | D02069 |




| Item | Order  | Description     | Model                 | OEM    |
|------|--------|-----------------|-----------------------|--------|
| 1    | 416746 | 3000W/230V      | RF8S, RF8DS           | D02023 |
| 2    | 416740 | 5000W/3 x 230 V | RF5SP, RF8DSP, RF12SP | D02027 |
| 3    | 416739 | 3800W/3 x 230V  | RF12S, RF12DS         | D02025 |




| Item | Order  | Description | Model         | OEM    |
|------|--------|-------------|---------------|--------|
| 1    | 416741 | 4000W/230V  | RF14S, RF14DS | D02028 |
| 2    | 416742 | 6000W/230V  |               | D02099 |



| Item | Order  | Description               | Model                          | OEM    |
|------|--------|---------------------------|--------------------------------|--------|
| 1    | 375109 | safety thermostat, 1-pole | RF3/5/8/12, RF14/25            | A06004 |
| 2    | 375418 | safety thermostat, 3-pole | RF8SP, RF8DSP, RF12SP, RF12DSP | A06012 |
| 3    | 345060 | micro switch              | RF_                            | A07011 |
| 4    | 359287 | signal lamp               |                                | A08001 |



| Item | Order  | Description        | Model                          | OEM    |
|------|--------|--------------------|--------------------------------|--------|
| 1    | 375177 | thermostat, 1-pole | RF3/5/8/12                     | A06018 |
| 2    | 375417 | thermostat, 3-pole | RF8SP, RF8DSP, RF12SP, RF12DSP | A06005 |
| 3    | 110650 | knob               | RF3/5/8/12                     | A14042 |



| Item | Order  | Description     | Model                         | OEM    |
|------|--------|-----------------|-------------------------------|--------|
| 1    | 300104 | selector switch |                               | A01002 |
| 2    | 375506 | thermostat      | RF14S, RF14DS, RF25S, RF25DS, | A06026 |
| 3    | 110651 | knob            |                               | A06007 |
| 4    | 550459 | terminal board  |                               | A14078 |
|      |        |                 |                               | A16004 |



| Item | Order  | Description | Model      | OEM    |
|------|--------|-------------|------------|--------|
| 1    | 693029 | basket, 2 l | RF3_       | F04002 |
| 2    | 693026 | basket, 4 l | RF5_, RF12 | F04004 |
| 3    | 693017 | basket, 6 l | RF8_       | F04006 |



| Item | Order  | Description  | Model        | OEM    |
|------|--------|--------------|--------------|--------|
| 1    | 693025 | basket, 8 l  | RF12_        | F04008 |
| 2    | 693028 | basket, 7 l  | RF14_, RF25  | F04017 |
| 3    | 693027 | basket, 14 l | RF14_, RF25_ | F04009 |



| Pos. | Order  | Description | Model     | Vergl..-Nr. |
|------|--------|-------------|-----------|-------------|
| 1    | 110921 | handle      | universal | A15001      |

R

## Hot cupboards




| Item | Order  | Description  | Model | OEM    |
|------|--------|--------------|-------|--------|
| 1    | 601017 | motor compl. | RE2   | A03006 |
| 2    | 416731 | 1500W/230V   |       | D02043 |
| 3    | 541063 | thermometer  |       | A18010 |



| Item | Order  | Description     | Model | OEM    |
|------|--------|-----------------|-------|--------|
| 1    | 550112 | connector block | RE2   | A16003 |
| 2    | 301202 | switch          |       | A07030 |
| 3    | 359647 | halogen lamp    |       | A18003 |
| 4    | 359043 | signal lamp     |       | A08008 |

no picture



| Item | Order  | Description     | Model | OEM    |
|------|--------|-----------------|-------|--------|
| 1    | 346374 | selector switch | RE2   | A01008 |
| 2    | 350043 | timer           |       | A02010 |
| 3    | 375005 | thermostat      |       | A06002 |
| 4    | 110651 | knob            |       | A14078 |