


Spare parts suitable for modular ranges



Spare parts suitable for single devices





TABLE OF CONTENTS

Open tops (gas/electric)



page 5

Ovens (gas/electric)




page 8

Fry tops (gas/electric)



page 10

Roasting shelves (electrical)



page 11

Grillvapor (gas)



page 12


TABLE OF CONTENTS

Pasta cookers (gas/electric)



page 13

Chip scuttles (electric)



page 14

Fryers (gas/electric)




page 14

Toasters (electrical)




page 17

Salamanders (gas/electric)



page 17

Crepes makers (gas/electric)



page 19

TABLE OF CONTENTS

Hot dog grills (electrical)




page 20

Table cookers (gas/electric)




page 20

Bains-marie/hot cupboards (electric)




page 22

Gyros grills (gas/electric)



page 23

Pizza ovens/fryers (electric)



page 25

Open tops (gas)



Item	Order	Description	Model	OEM
1	103066	burner cover, 80mm	TOP G/2G, PC 1G/2G, BSC4FG/C8FG	068098
2	103065	burner ring, 80mm		068099
3	104100	burner base, 80mm		068085
4	104101	jet holder		068097




Item	Order	Description	Model	OEM
1	103068	burner cover, 100mm	TOP G/2G, PC 1G/2G	068067
2	103067	burner ring, 100mm		068070
3	104102	burner base, 100mm		068064
4	104103	jet holder		068063



Item	Order	Description	Model	OEM
1	101697	gas tap	TOP G/2G,	062106
2	102056	thermocouple	PC 1G/2G	068025



Item	Order	Description	Model	OEM
1	110444	knob/blue, 55mm	TOP G/2G, PC 1G/2G	061078
2	110494	symbol/yellow		082336
3	110469	knob/black, 55mm		061080
4	110492	symbol/grey		082346



Item	Order	Description	Model	OEM
1	100729	electrode	TOP G/2G, PC 1G/2G	068032
2	100036	ignition cable		068033
3	101009	ignition unit		068160
4	301195	ignition switch		068163




Item	Order	Description	Model	OEM
1	105029	burner cover, 80mm	TOP G/2G,	069200/A
2	105030	burner base, 80mm	PC1G/2G,	069205
3	105038	burner gasket, 80mm	BSC4FG/C8FG,	020822
4	105032	burner	PC47G/87G,	06912
5	105033	jet holder	BSC4FE80	062150/A



Item	Order	Description	Model	OEM
1	105018	burner cover, 100mm	PC 1G/2G, BSC4FE80, BSC4FG/C8FG, PC47G/87G/127G	069201/A
2	105019	burner base, 100mm		069206
3	105031	burner gasket, 100mm		020824
4	105034	burner		006911
5	105033	jet holder		062150/A




Item	Order	Description	Model	OEM
1	101698	gas tap	TOP G/2G, PC 16/2G,	062145
2	102056	thermocouple	BSC4FG/C8FG, BSC4FE80, PC47G/87G/127G	068025



Item	Order	Description	Model	OEM
1	110444	knob/blue, 55mm	TOP G/2G,	061078
2	110494	symbol/yellow	PC 16/2G,	082336
3	110469	knob/black, 55mm	BSC4FG/C8FG,	061080
4	110492	symbol/grey	BSC4FE80, PC47G/87G/127G	082346



Item	Order	Description	Model	OEM
1	105010	burner cover, 100mm	PC47G/87G/127G, C87FE/FG, C127FE/FG	069201
2	105016	burner, 100mm		069111
3	105031	burner gasket, 100mm		020824
4	105017	burner		069110



Item	Order	Description	Model	OEM
1	110384	knob/blue, 65mm	PC 1G/2G,	061077
2	110493	symbol/yellow	BSC4FG/C8FG,	082306
3	110389	knob/black, 65mm	BCC4FE80,	061079
4	111841	symbol/grey	PC47G/87G/127G	082316



Item	Order	Description	Model	OEM
1	106015	gas tap	PC47G/87G/127G,	062111
2	102056	thermocouple	C87FE/FG, C127FE/FG	068025




Item	Order	Description	Model	OEM
1	102832	electrode	TOP G/2G, PC1G/2G,	068195
2	101009	ignition unit, 1,5V	BSC4FG/C8FG, BCC4FE,	068160
3	301195	ignition switch	PC47G/87G/127G	068163




Item	Order	Description	Model	OEM
1	110444	knob/blue, 55mm	PC47G/87G/127G, C87FE/FG, C127FE/FG	061078
2	110494	symbol/yellow		082336
3	110469	knob/black, 55mm		061080
4	110492	symbol/grey		082346



Item	Order	Description	Model	OEM
1	105879	burner cover, 80mm	PC47G/87G/127G, C87FE/FG, C127FE/FG	069200
2	105880	burner base, 80mm		069113
3	105038	burner gasket, 80mm		020822
4	105881	burner, 80mm		069112




Item	Order	Description	Model	OEM
1	110384	knob/blue, 65mm	PC47G/87G/127G, C87FE/FG, C127FE/FG	061077
2	110493	symbol/yellow		082306
3	110389	knob/black, 65mm		061079
4	111841	symbol/grey		082316




Item	Order	Description	Model	OEM
1	100821	electrode		068150
2	101009	ignition unit/2 outputs	PC47G/87G/127G,	068160
3	101018	ignition unit/4 outputs	C87FE/FG,	068161
4	101019	ignition unit/6 outputs	C127FE/FG	068162
5	301195	ignition switch		068163


Open tops (electric)



Item	Order	Description	Model	OEM
1	490012	1500W/230 V, 145mm		071008, 071075
2	490018	2000W/230 V, 180mm		071009, 071076
3	359048	signal lamp/yellow, 12mm	TOP E/2E,	076006
4	359137	signal lamp/yellow, 9mm	PC1E/2E,	076026
5	300025	7-tact switch	BS/C4FE	073007




Item	Order	Description	Model	OEM
1	110444	knob/blue, 55mm		061078
2	110495	symbol/yellow	TOP E/2E,	082338
3	110469	knob/black, 55mm	PC1E/2E,	061080
4	110496	symbol/grey	BS/C4FE	082348




Item	Order	Description	Model	OEM
1	110384	knob/blue, 65mm		061077
2	111842	symbol/yellow	TOP E/2E,	082308
3	110389	knob/black, 65mm	PC1E/2E,	061079
4	111843	symbol/grey	BS/C4FE	082318


Open tops/ceramic (gas)



Item	Order	Description	Model	OEM
1	105885	burner		004608
2	106017	gas valve	TOPVCG	068147
3	370365	solenoid valve		092255



Item	Order	Description	Model	OEM
1	102373	ignition control modul		074031
2	101861	electrode unit	TOPVCG	004608.1



Item	Order	Description	Model	OEM
1	101862	electrode, 2,8 faston		068122.1
2	101863	electrode, 6,3 faston	TOPVCG	068122.2

Open tops/ceramic (electrical)




Item	Order	Description	Model	OEM
1	490045	1200W/230V		071011
2	490047	2100W/230V		071010
3	300025	7-position switch	PC1V/2V,	073007
4	359048	signal lamp/yellow, 12mm	PC47V/87V,	076006
5	359137	signal lamp/yellow, 9mm	BS/C4FV	076026



Item	Order	Description	Model	OEM
1	490024	1200W/230V	PC1V/2V, PC47V/87V, BS/C4FV	071011.1
2	490026	2100W/230V		071010.1
3	380015	energy regulator		073010
4	359048	signal lamp/yellow, 12mm		076006
5	359137	signal lamp/yellow, 9mm		076026

Ovens (gas)



Item	Order	Description	Model	OEM
1	105882	burner	C87FG, C127FG	068187
1	105883	burner		068168
2	106016	gas thermostat		068065



Item	Order	Description	Model	OEM
1	110384	knob/blue	C87FG, C127FG	061077
2	111892	symbol		
3	110389	knob/black		061079
4	111847	symbol		082369




Item	Order	Description	Model	OEM
1	101853	electrode	C87FG, C127FG	068195
2	102060	thermocouple		068138
3	101009	ignition unit, 2 outputs		068160
4	301195	ignition switch		068163


Ovens (electric)




Item	Order	Description	Model	OEM
1	601123	motor/compl.	BS/C4FG,	079510
2	418267	2500W/230V	BS/C8FG,	071041
3	418266	1800/230V (grill)	BS/C4FE, BS/C4FV	071065



Item	Order	Description	Model	OEM
1	110444	knob/blue, 55mm	PC1V/2V	061078
2	110495	symbol/yellow (7-position switch)		082338
3	111844	symbol/yellow (energy regulator)		082335



Item	Order	Description	Model	OEM
1	110469	knob/black, 55mm	PC1V/2V, PC1V/2V	061080
2	110496	symbol/grey (7-position switch)		082348
3	111845	symbol/grey (energy regulator)		082345




Item	Order	Description	Model	OEM
1	110384	knob/blue, 65mm	PC47V/87V, BS	061077
2	111842	symbol/yellow (7-position switch)		082308
3	110404	symbol/yellow (energy regulator)		082305



Item	Order	Description	Model	OEM
1	110389	knob/black, 65mm		061080
2	111843	symbol/grey (7-tact switch)		082318
3	111846	symbol/grey (energy regulator)		082315



Item	Order	Description	Model	OEM
1	345678	micro switch	BS/C4FG,	073017
2	359718	bulb + housing/compl.	BS/C8FG,	076008
3	359610	bulb	BS/C4FV	076007



Item	Order	Description	Model	OEM
1	601123	motor/compl.	BS/C4FE80,	079510
2	301231	selector switch	C127FE,	073034
3	375719	thermostat	C87FE/FV	072032




Item	Order	Description	Model	OEM
1	301016	changeover switch	BS/C4FG,	073025
2	359027	signal lamp/green	BS/C8FG,	076005
3	359048	signal lamp/yellow	BS/C4FE,	076006



no picture!

Item	Order	Description	Model	OEM
1	110384	knob/blue	BS/C4FE80,	061077
2	111848	symbol, 250°C	C127FE,	082303
3	111850	symbol (switch)	C87FE/FV	082339




Item	Order	Description	Model	OEM
1	375719	thermostat, 250°C	BS/C4FG,	072032
2	300001	switch	BS/C8FG,	073015

Ovens (mechanical)




Item	Order	Description	Model	OEM
1	690324	hinge/right	universal	055904
2	690349	hinge/left		055905




Item	Order	Description	Model	OEM
1	110384	knob/blue, 65mm	BS/C4FG,	061077
2	111848	symbol/yellow, 250°C	BS/C8FG,	082303
3	110389	knob/black, 65mm	BS/C4FE,	061079
4	111849	symbol/grey, 250°C	BS/C4FV	082313



Item	Order	Description	Model	OEM
1	900508	door seal	BS/C8FG,	068201
2	690377	handle	C87FE/FG,	065032




Item	Order	Description	Model	OEM
1	418227	2600 W/230 V (upper)	BS/C4FE80,	071084
2	418228	1500 W/230 V	C127FE,	071068
3	418267	2500 W/230 V (air circulation)	C87FE/FV	071041




Item	Order	Description	Model	OEM
1	900509	door seal	BS/C4F80	068203
2	690377	handle		065032

Fry tops (gas)



Item	Order	Description	Model	OEM
1	105884	burner	FT1G,	068058
2	106016	gas thermostat	FT2G_	068065
3	102056	thermocouple	FT47G_	068025
			FT87G_	




Item	Order	Description	Model	OEM
1	100819	electrode	FT1G,	068057
2	301195	ignition switch	FT2G_	068163
3	101009	ignition unit	FT47G_	068160
			FT87G_	




Item	Order	Description	Model	OEM
1	110384	knob/blue	FT1G,	061077
2	111851	symbol/yellow		082307
3	110389	knob/black	FT47G_	061079
4	111852	symbol/grey	FT87G_	082317

Fry tops (electric)




Item	Order	Description	Model	OEM
1	416161	1000W/230V	FT1, FT2,	071027
			TOP_FT	
2	418229	1200W/230V	FT47_	071007
			FT87_	




Item	Order	Description	Model	OEM
1	418230	4000W/230V	FT1, FT2,	071096
			TOP_FT	
2	416166	3500W/230V	FT47_	071098
			FT87_	



Item	Order	Description	Model	OEM
1	380213	contactor, 20A	universal	073050
2	359027	signal lamp/green, 12mm		076005
3	359048	signal lamp/yellow, 12mm		076006
4	359136	signal lamp/green		076025
5	359137	signal lamp/yellow		076026




Item	Order	Description	Model	OEM
1	375721	safety thermostat, 290°C	FT_C,	072025
2	375719	thermostat, 250°C		072032,
			TOP_FTC	072024




Item	Order	Description	Model	OEM
1	375327	thermostat, 300 °C	TOP_FT, FT_	072005.1, 072005
2	300001	switch (2-pole)		073015
3	300129	main switch (2-pole)	universal	073016


Roasting shelves (electrical)




Item	Order	Description	Model	OEM
1	418231	2300 W/230 V	RG70, RG105	071025
2	418232	3100 W/230 V	TO RG1/2	071034




Item	Order	Description	Model	OEM
1	301002	switch		073013
2	370365	solenoid valve		062081
3	359027	signal lamp/green, 12 mm		076005
4	359048	signal lamp/yellow, 12 mm		076006
5	359136	signal lamp/green		076025
6	359137	signal lamp/yellow		076026




Item	Order	Description	Model	OEM
1	300176	switch		073005
2	380015	energy regulator		073010




Item	Order	Description	Model	OEM
1	110444	knob/blue, 55 mm		061078
2	110476	symbol/yellow (0 - I)	TOP RG1, TOP RG2	082330
3	111844	symbol/yellow (energy regulator)		082335




Item	Order	Description	Model	OEM
1	110469	knob/black, 55 mm		061080
2	111854	symbol/grey (0 - I)	TOP RG1, TOP RG2	082340
3	111845	symbol/grey (energy regulator)		082345



Item	Order	Description	Model	OEM
1	110444	knob/blue, 55 mm		061078
2	110476	symbol/yellow (0 - I)	TOP_FT	082330
3	111853	symbol/yellow, 250 °C		082333
4	110477	symbol/yellow, 300 °C		082334




Item	Order	Description	Model	OEM
1	110469	knob/black, 55 mm		061080
2	111854	symbol/grey (0 - I)	TOP_FT	082340
3	111855	symbol/grey, 250 °C		082343
4	111856	symbol/grey, 300 °C		082344




Item	Order	Description	Model	OEM
1	110384	knob/blue, 65 mm		061077
2	110403	symbol/yellow (0 - I)	FT1, F2, FT47, FT87	082300
3	111848	symbol/yellow, 250 °C		082303
4	111857	symbol/yellow, 300 °C		082304



Item	Order	Description	Model	OEM
1	110389	knob/black, 65 mm	FT1, FT2, FT47, FT87	061079
2	110484	symbol/grey (0 - I)		082310
3	111849	symbol/grey, 250 °C		082313
4	110478	symbol/grey, 300 °C		082314



Item	Order	Description	Model	OEM
1	110384	knob/blue, 65mm	RG70, RG105	061077
2	110403	symbol/yellow (0 - I)		082300
3	110404	symbol/yellow (energy regulator)		082305




Item	Order	Description	Model	OEM
1	110389	knob/black, 65mm	RG70, RG105	061079
2	110484	symbol/grey, (0 - I)		082310
3	111846	symbol/grey (energy regulator)		082315




Item	Order	Description	Model	OEM
1	514062	drain tap	RG70, RG105	062055
2	514329	connection		062056
3	514063	drain pipe		062010
4	514331	lever/compl.		062075


Grillvapor (gas)




Item	Order	Description	Model	OEM
1	101397	gas tap	GMV40/70,	062116
2	102041	thermocouple	GMV75/70,	068167
3	100046	pilot burner	GMV110/70	068043



Item	Order	Description	Model	OEM
1	102374	electrode	GMV40/70,	068102
2	100036	ignition cable	GMV75/70,	068033
3	301195	ignition switch	GMV110/70	068163



Item	Order	Description	Model	OEM
1	101009	ignition unit (2 outputs)	GMV40/70,	068160
2	101018	ignition unit (4 outputs)	GMV75/70, GMV110/70	068161




Item	Order	Description	Model	OEM
1	110498	knob/blue, 65mm, 8x6,5mm	GMV40/70, GMV75/70,	061081
2	110493	symbol/yellow	GMV110/70	082306




Pos.	Order	Description	Model	OEM
1	540747	drain tap	GMV40/70, GMV75/70, GMV110/70	062001

Pasta cookers




Item	Order	Description	Model	OEM
1	416152	500W/230V	CP.	071014.1
2	418233	1100W/230V	CP67M	071044
3	418229	1200W/230V		071007




Item	Order	Description	Model	OEM
1	380213	contactor	universal	073050
2	300176	switch		073005
3	380015	energy regulator		073010



Item	Order	Description	Model	OEM
1	370365	solenoid valve	universal	062081
2	359027	signal lamp/green, 12mm		076005
3	359048	signal lamp/yellow, 12mm		076006
4	359136	signal lamp/green, 9mm		076025
5	359137	signal lamp/yellow, 9mm		076026



Item	Order	Description	Model	OEM
1	110384	knob/blue, 65mm	universal	061077
2	110403	symbol/yellow (0 - I)		082300
3	110404	symbol/yellow (energy regulator)		082305




Item	Order	Description	Model	OEM
1	110389	knob/black, 65mm	universal	061079
2	110484	symbol/grey (0 - I)		082310
3	111846	symbol/grey (energy regulator)		082315




Pos.	Order	Description	Model	OEM
1	540747	drain tap	universal	062001


Bains-marie (electric)



Item	Order	Description	Model	OEM
1	416161	1000W/230V	BM1, BM2, BM47, BM67	071027
2	300129	switch		073016
3	390006	thermostat, 50°C		072029




Item	Order	Description	Model	OEM
1	359027	signal lamp/green, 12mm	universal	076005
2	359048	signal lamp/yellow, 12mm		076006
3	359136	signal lamp/green, 9mm		076025
4	359137	signal lamp/yellow, 9mm		076026



Item	Order	Description	Model	OEM
1	110384	knob/blue, 65mm	universal	061077
2	110403	symbol (0 - I)		082300
3	110483	symbol, 90°C		082301

S

Suitable for Star 10



Item	Order	Description	Model	OEM
1	110389	knob/black, 65mm		061079
2	110484	symbol (0 - I)		082310
3	110490	symbol, 90°C		082311




Item	Order	Description	Model	OEM
1	514062	drain tap		062055
2	514329	connection	BM47, BM67	062056
3	514063	drain pipe		062010
4	514331	lever/compl.		062075




Pos.	Order	Description	Model	OEM
1	540747	drain tap	BM1, BM2	

Chip scuttles (electric)




Item	Order	Description	Model	OEM
1	415103	650W/230V		071053
2	380015	energy regulator	SF47	073010
3	359048	signal lamp/yellow		076006



Item	Order	Description	Model	OEM
1	110384	knob/blue, 65mm		061077
2	110404	symbol		082305
3	110389	knob/black, 65mm	SF47	061079
4	111846	symbol		082315


Fryers (gas)




Item	Order	Description	Model	OEM
1	105885	burner	universal	004608
2	101188	Eurosit controller	F121GT, F_GTM, F47IRGT	068165




Item	Order	Description	Model	OEM
1	106017	tandem valve	F121G	068147
2	101189	tandem valve	F_GM,	068182
3	102373	ignition control module	F_IRG, F121G	074031




Item	Order	Description	Model	OEM
1	100046	pilot burner	F121GT,	068043
2	102374	electrode	F47IRGT,	068102
3	102041	thermocouple	F_GTM	068167




Item	Order	Description	Model	OEM
1	100036	ignition cable	F121GT,	068033
2	301195	ignition switch	F47IRGT,	068163
3	101009	ignition unit/2 outputs	F_GTM	068160



Item	Order	Description	Model	OEM
1	101861	electrode unit	F_GM,	004608.1
2	101862	electrode (plug), 2,8mm	F_IRG,	068122.1
3	101863	electrode (plug), 6,3mm	F121G	068122.2




Item	Order	Description	Model	OEM
1	375722	safety thermostat, 240°C	F121G	072002
2	375263	safety thermostat, 230°C	F121G, F_IRG, F_GM	0720281




Item	Order	Description	Model	OEM
1	375720	thermostat	F121G, F_IRG, F_GM	0720201, 072051
2	300129	switch/2-pole	universal	073016



Item	Order	Description	Model	OEM
1	359027	signal lamp/green, 12mm		076005
2	359048	signal lamp/yellow, 12mm		076006
3	359026	signal lamp/red, 12mm		076004
4	359136	signal lamp/green, 9mm		076025
5	359137	signal lamp/yellow, 9mm		076026



Item	Order	Description	Model	OEM
1	110384	knob/blue, 65mm		061077
2	110403	symbol/O-I		082300
3	111858	symbol/180°C		082302




Item	Order	Description	Model	OEM
1	110389	knob/black, 65mm		061079
2	110484	symbol/O-I		082310
3	110525	symbol/180°C		082312


Fryers (electric)




Item	Order	Description	Model	OEM
1	416172	3000W/230V	F101/102, F121/122, F121M/122M	071005
2	417338	6000W/230V	F101R, F102R, F47110, F67/10	071069
3	416166	3500W/230V	F47/15, F47IR, F87/15, F87IR	071098




Item	Order	Description	Model	OEM
1	345678	micro switch		073003
2	380213	contactor		073050
3	550041	sensor clamp	universal	063001
4	550042	sensor clamp		063002



Item	Order	Description	Model	OEM
1	300129	switch, 2-pol, 0-I		073016
2	300176	switch, 3-pol, 0-I		073005




Item	Order	Description	Model	OEM
1	110389	knob/black, 65mm		061079
2	110484	symbol, 0-I	universal	082310
3	110525	symbol, 180°C		082312



Item	Order	Description	Model	OEM
1	375263	safety thermostat, 1-pole, 230°C	F101, F102	072028.1
2	375290	safety thermostat, 3-pole, 230°C	F121, F122, F121M, F122M, F101R, F102R, F47, F67, F87	072027




Item	Order	Description	Model	OEM
1	540747	drain tap		
2	540745	drain tap	F47IRG	062012



Item	Order	Description	Model	OEM
1	375720	thermostat, 1-pole, 180°C	F101, F102, F121, F122, F121M, F122M	072020.1, 072051
2	375718	thermostat, 1-pole, 180°C	F101R, F102R, F47-, F67, F87-	072001, 072001.1



Item	Order	Description	Model	OEM
1	359027	signal lamp/green, 12mm		076005
2	359048	signal lamp/yellow, 12mm		076006
3	359026	signal lamp/red, 12mm	universal	076004
4	359136	signal lamp/green, 9mm		076025
5	359137	signal lamp/yellow, 9mm		076026



Item	Order	Description	Model	OEM
1	110384	knob/blue, 65mm		061077
2	110403	symbol, 0-I	universal	082300
3	111858	symbol, 180°C		082302

Fryer baskets



Item	Order	Description	Model	OEM
1	970241	210x280x110mm, 10l/12l	F101, F102, F121, F122	057106
2	970438	280x350x110, 15l	F47/15, F87/15	057122.1


Toasters




Item	Order	Description	Model	OEM
1	416152	500W/230V	T3, T6, T Grill	071014.1
2	416153	600W/230V	T9, T9-2, S9KER	071051.1
3	345747	rocker switch	T3 - T6	073018, 073009



Item	Order	Description	Model	OEM
1	301060	rocker switch	T9, T9-2, S9KER	073004
2	359027	signal lamp/green		076005
3	359048	signal lamp/yellow		076006




Item	Order	Description	Model	OEM
1	380015	energy regulator	T9, T9-2, S9KER	073010
2	350032	timer, 15min	universal	073008
3	110382	knob		061050
4	110482	knob		061037




Pos.	Order	Description	Model	OEM
1	690010	pliers	universal	PIN-T

Salamanders (gas)



Item	Order	Description	Model	OEM
1	105007	burner	ST650G, SA650G, SAM650G	068077
2	105009	burner	ST900G	069040
3	101697	gas tap	universal	062106




Item	Order	Description	Model	OEM
1	345678	ignition switch	universal, 230V PC	073017
2	101002	ignition unit		068034
3	100819	electrode		068057



Item	Order	Description	Model	OEM
1	301195	ignition switch	universal, 15V DC	068163
2	101009	ignition unit, 1,5V		068160
3	100819	electrode		068057




Item	Order	Description	Model	OEM
1	102056	thermocouple, 600mm	ST650G	068025
1	102059	thermocouple, 1200mm	SA650G, ST900G, SAM650G	068135
2	102067	nut, M8 x 1	universal	



Item	Order	Description	Model	OEM
1	110409	knob, 50mm	universal	061025
2	110384	knob/blue, 65mm		061077
3	110493	symbol		082306
4	110389	knob/black, 65mm		061079
5	111841	symbol		082316


Salamanders (electrical)




Item	Order	Description	Model	OEM
1	416154	2500W/230V	ST400	071018
2	416155	2000W/230V	ST650	071019
3	416156	3000W/230V	ST650B	071036
4	416153	600W/230V	SAG50KER, SAM650	071051.1




Item	Order	Description	Model	OEM
1	359027	signal lamp/green	universal	076005
2	359048	signal lamp/yellow		076006
3	110409	knob, 50mm		061025



Item	Order	Description	Model	OEM
1	300129	switch/0-I	universal	073016
2	380015	energy regulator		073010



Item	Order	Description	Model	OEM
1	110384	knob/blue	universal	061077
2	110403	symbol/0-I		082300
3	110404	symbol/energy regulator		082305



Item	Order	Description	Model	OEM
1	110389	knob/black	universal	061079
2	110484	symbol/0-I		082310
3	111846	symbol/energy regulator		082315

Salamanders (mechanical)



Item	Order	Description	Model	OEM
1	693120	hand protection shield	ST400, ST650B, ST650G	055814
2	693119	hand protection shield		055807
3	693121	handle		065007
4	693122	device leg		064012
5	693442	device leg		064001




Item	Order	Description	Model	OEM
1	693443	grid	ST400	055809
2	693444	grid	ST650, SA650, SAM650	055810
3	693445	grid	ST900	057116


no picture!

Pos.	Order	Description	Model	OEM
1	693446	handle	SA650, SAM650	065014

Salamanders (mechanical)



Item	Order	Description	Model	OEM
1	345730	rotary switch		073012
2	345640	contactor block	SAM650,	079003
3	345735	micro switch NO	SAM650G	073002
4	345736	micro switch NC		073011




Item	Order	Description	Model	OEM
1	693054	mechanical	SAM650,	055813
2	500498	gear motor/compl.	SAM650G	079501

Crepes makers (gas)



Item	Order	Description	Model	OEM
1	105018	burner cover, 100mm		069201/A
2	105019	burner base	CREP1G,	069206
3	105017	burner	CREP2G	069210
4	105031	gasket		020824




Item	Order	Description	Model	OEM
1	105010	burner cover, 100mm		069201
2	105016	burner base	CREP1G,	069111
3	105017	burner	CREP2G	069210
4	105031	gasket		020824



Item	Order	Description	Model	OEM
1	101698	gas tap	CREP1G,	062145
2	102056	thermocouple	CREP2G	068025




Item	Order	Description	Model	OEM
1	301195	ignition switch		068163
2	101009	ignition unit	CREP1G,	068160
3	100821	electrode	CREP2G	068150




Item	Order	Description	Model	OEM
1	110444	knob, 55mm		061078
2	110494	symbol	CREP1G,	082336
3	110469	knob, 55mm	CREP2G	061080
4	110492	symbol		082346


Crepes makers (electric)




Item	Order	Description	Model	OEM
1	416157	2400W/230V		071066
2	359027	signal lamp/green, 12mm	CREP1E,	067005
3	359048	signal lamp/yellow, 12mm	CREP2E	067006




Item	Order	Description	Model	OEM
1	300129	switch, 2-pole		073016
2	300176	switch, 3-pole	CREP1E,	073005
3	375327	thermostat, 300°C	CREP2E	072005, 072005.1



Item	Order	Description	Model	OEM
1	110444	knob/blue, 55mm	CREP1E, CREP2E	061078
2	110476	symbol, 0-I		082330
3	110477	symbol, 300°C		082334




Item	Order	Description	Model	OEM
1	110444	knob/blue, 55mm	universal	061078
2	111844	symbol		082335
3	110469	knob/black, 55mm		061080
4	111845	symbol		082345



Item	Order	Description	Model	OEM
1	110469	knob/black, 55mm	CREP1E, CREP2E	061080
2	111854	symbol, 0-I		082340
3	111856	symbol, 300°C		082344

Hot dog grills (electrical)



Item	Order	Description	Model	OEM
1	416158	500W/230V	STAR SP4, STAR SW	071033
2	416487	750W/230V	STAR SP6, STAR HD/HD4	071015
3	693094	aluminum skewer	STAR HD/HD4, STR SP4/SP6	055804



Item	Order	Description	Model	OEM
1	359027	signal lamp	universal	076005
2	390158	safety thermostat, 140°C		072011
3	380015	energy regulator		073010
4	110482	knob/blue, 42mm		061050
5	110382	knob/black, 42mm		061037



Item	Order	Description	Model	OEM
1	693097	aluminium shell	STAR SW,	058501
2	693002	glass container	STAR HD,	066006
3	693468	insert (CNS)	STAR HD4	057501



Item	Order	Description	Model	OEM
1	693098	cap	STAR SW,	058502
2	111782	handle	STAR HD, STAR HD4	061003
3	690083	handle	universal	065005
4	693442	junction		064001

Table cookers (gas)



Item	Order	Description	Model	OEM
1	105879	burner cover, 80mm	HP465/2G, HP885/4G	069200
2	105880	burner base, 80mm		069113
3	105881	burner, 80mm		069112
4	105038	gasket, 80mm		020822



Item	Order	Description	Model	OEM
1	105010	burner cover, 100mm	HP1G,	069201
2	105016	burner base, 100mm	HP2G,	069111
3	105017	burner, 100mm	HP465/2G,	069210
4	105031	gasket, 100mm	HP865/4G	020824




Item	Order	Description	Model	OEM
1	105029	burner cover, 80mm		069200/17
2	105030	burner base, 80mm		069205
3	105032	burner, 80mm	HP465/2G,	006912
4	105038	gasket, 80mm	HP885/4G	020822
5	105033	burner holder		062150/A



Item	Order	Description	Model	OEM
1	105018	burner cover, 100mm		069201/17
2	105019	burner, 100mm	HP1G,	069206
3	105034	burner, 100mm	HP2G,	006911
4	105031	gasket, 100mm	HP465/2G,	020824
5	105033	burner holder	HP865/4G	062150/17




Item	Order	Description	Model	OEM
1	101698	gas tap	HP1G,	062145
2	102056	thermocouple	HP2G,	068025
3	102067	nut	HP465/2G,	-
			HP865/4G	




Item	Order	Description	Model	OEM
1	100821	electrode		068150
2	301195	ignition switch, 1,5V	HP1G,	068163
3	101009	ignition unit	HP2G	068160



Item	Order	Description	Model	OEM
1	301195	ignition switch		068163
2	101009	ignition unit, 2 outputs, 1,5V	HP465/2G,	068160
3	101018	ignition unit, 4 outputs, 1,5V	HP865/4G	068161
4	101853	electrode		068195



Item	Order	Description	Model	OEM
1	210225	top grate, 1--burner	HP1G/2G	059007
2	210226	top grate, 2--burner	HP465/2G,	059006
			HP865/4G	



Item	Order	Description	Model	OEM
1	110444	knob/blue, 55mm		061078
2	110494	symbol		082336
3	110469	knob/black, 55mm	universal	061080
4	110492	symbol		082346

Table cookers (electrical)




Item	Order	Description	Model	OEM
1	490018	2000W/230V		071009
2	359048	signal lamp/yellow	HP1E, HP2E	076006
3	300025	7-position switch		073007




Item	Order	Description	Model	OEM
1	693442	junction	universal	064001
2	515059	drain valve	BMZR	062030
3	540747	drain tap		062001

Bains-marie (electric)



Item	Order	Description	Model	OEM
1	416161	1000W/230V		071027
2	300129	switch	CR/200C	073016
3	390006	thermostat		072029


Bains-marie (electric)




Item	Order	Description	Model	OEM
1	416160	300W/230V (PTC)	BME_	079251
2	416161	1000W/230V	BMZ_, BMZR_	071027




Item	Order	Description	Model	OEM
1	359027	signal lamp/green		076005
2	359048	signal lamp/yellow	CR/200C	076006
3	110482	knob, 50mm		061037



Item	Order	Description	Model	OEM
1	110384	knob/blue, 65mm		061077
2	110403	symbol, 0-I	CR/200C	082300
3	110483	symbol, 90°C		082301



Item	Order	Description	Model	OEM
1	110389	knob/black, 65mm		061079
2	110484	symbol, 0-I	CR/200C	082310
3	110490	symbol, 90°C		082311




Item	Order	Description	Model	OEM
1	301060	rocker switch	universal	073004
2	359137	signal lamp/9mm		076026
3	390006	thermostat, 90°C	BMZ_, BMZR_	072029
4	110382	knob		061050



Item	Order	Description	Model	OEM
1	515059	drain valve		062030
2	540745	drain tap		062012
3	700308	swivel castor set, 4-piece with tear-off roller		066024

Hot cupboards




Item	Order	Description	Model	OEM
1	416809	700W/230V	universal	071080
2	301060	rocker switch		073004
3	359137	signal lamp/yellow	SP40, SP80	076026
4	390006	thermostat		072029



Item	Order	Description	Model	OEM
1	300001	switch, 2-pole	SP40Y, SP80Y	073015
2	390094	thermostat (digital)		072040
3	110482	knob	universal	061037

Roller grills




Item	Order	Description	Model	OEM
1	416183	170W/230V	Rolly 5, Rolly 16	
2	416184	170W/230V	Rolly 5S	
3	416185	170W/230V	Rolly 8L	




no longer available

Item	Order	Description	Model	OEM
1	301003	switch		
2	345598	signal lamp, 400V	Rolly 5, Rolly 5S, Rolly 8L, Rolly16	
3	375002	thermostat		
4	110529	knob		




Item	Order	Description	Model	OEM
1	500497	motor	Rolly 5/5S, Rolly8L/16	
2	693056	drive chain		

Gyros grills (gas)




Item	Order	Description	Model	OEM
1	105035	burner	GY-INO10G	004610
2	105036	burner	GY40G, GY60G, GY80G, GY100G	062142
3	105037	burner	GY60G, GY80G, GY100G	062143



Item	Order	Description	Model	OEM
1	210147	burner grid	GYINO10G	056427
2	210149	burner grid	GYINO40G	056451
3	210153	burner grid	GYINO60G	056452
4	210154	burner grid	GYINO80G	056453
5	210129	burner grid	GYINO100G	056454

S


Suitable for Star 10




Item	Order	Description	Model	OEM
1	101698	gas tap/jet outlet	GY40G-100G	062140
2	101699	gas tap/pipe outlet		062140
3	101833	T-fitting		062155



Item	Order	Description	Model	OEM
1	102056	thermocouple, 600mm	GY-INO10g, GY-INO30G	068025
2	102034	thermocouple, 600mm	GY40G-100G	068159




Item	Order	Description	Model	OEM
1	110444	knob/blue, 55mm	GY-INO10G, GY-INO30G	061078
2	110494	symbol		082336
3	110469	knob/black, 55mm		061080
4	110492	symbol		082346




Item	Order	Description	Model	OEM
1	110498	knob/blue, 65mm	GY40G-100G	061081
2	110493	symbol		082306


Gyros grills (electrical)



Item	Order	Description	Model	OEM
1	416163	2800 W/230V	GY-INO10E	071067/A
2	416164	1500 W/230V	GY40E, GY60E, GY80E, GY100E	071085
3	693052	ceramic stone		090005




Item	Order	Description	Model	OEM
1	416165	1500 W/230V	GY100E-VC	071097
2	416166	3500 W/230V	GY30EI, GY80EIR	071098
3	693053	glass		067023.1




Item	Order	Description	Model	OEM
1	300001	switch	universal	073015
2	300129	switch/0-I	GY30E-IR, GY80EIR	073016
3	380015	energy regulator	universal	073010



Item	Order	Description	Model	OEM
1	301060	rocker switch	40E-100E	073004
2	359027	signal lamp/green	universal	076005
3	359048	signal lamp/yellow		076006
4	550885	lamp holder outlet		078022




Item	Order	Description	Model	OEM
1	110444	knob/blue, 55mm		061078
2	110476	symbol/0-I		082330
3	111844	symbol/energy regulator		082335



Item	Order	Description	Model	OEM
1	110469	knob/black, 55mm		061080
2	111854	symbol/0-I		082340
3	111845	symbol/energy regulator		082345


Gyros grills (motor drive)



Item	Order	Description	Model	OEM
1	301060	rocker switch		073004
2	300129	switch/0-I	universal	073016
3	359027	signal lamp/green		076005
4	359028	signal lamp/yellow		076006




Item	Order	Description	Model	OEM
1	110444	knob/blue		061078
2	110476	symbol/0-I	universal	082330
3	110469	knob/black, 55mm		061080
4	111854	symbol/0-I		082340



Item	Order	Description	Model	OEM
1	500868	motor	GY-INO_	079515
2	500869	motor	GY40-100	079513

Gyros grills (mechanical)




Item	Order	Description	Model	OEM
1	693649	skewer plate	GI10-GY30	056422
2	693650	skewer plate	GY40-GY100	098025
3	693457	cotter	GY10-100	020102
4	693651	pivot bearing/compl.	GY40-GY100	059015




Pos.	Order	Description	Model	OEM
1	693652	skewer	GY10	056421
2	693653	skewer	GY30	056456
3	693654	skewer	GY40	059017
4	693655	skewer	GY60	059018
5	693656	skewer	GY80	059019
6	693657	skewer	GY100	059020


Pizza ovens (electric)



Item	Order	Description	Model	OEM
1	416162	1000W/230V		076018
2	359305	halogen lamp, 60W, 78,3mm	PIZZA41/42, PIZZA61S/62S	076018
3	693123	glass plate/halogen lamp		067020




Item	Order	Description	Model	OEM
1	375330	thermostat		072039
2	110389	knob/black, 65mm	PIZZA41/42, PIZZA61S/62S	061079
3	110497	symbol		082329/A




Item	Order	Description	Model	OEM
1	850015	firebrick, 620x305x25mm	PIZZA41/42, PIZZA61S/62S	-
2	110703	handle	PIZZA41/42	064013


Fryers (electric)




Item	Order	Description	Model	OEM
1	416167	2500W/230V	FE4, F4, F4+4	071055.1
2	416168	2500W/230V	FE6, F6, F6+6, FE8	071077




Item	Order	Description	Model	OEM
1	416169	3000W/230V	F8M, F8+8M	071052
2	416170	3000W/230V	F8T, F8+8T, F10, F10+10	071001



Item	Order	Description	Model	OEM
1	375720	thermostat, 180°C	universal	072020.1 072051
2	375263	safety thermostat		072028.1




Item	Order	Description	Model	OEM
1	300001	switch	FE4-8, F4-6	073015
2	300129	switch, 2-pole	F8-F10	073016
3	345678	micro switch	universal	073003



Item	Order	Description	Model	OEM
1	380213	contactor	F8T, F8+8T, F10, F10+10	073050
2	550138	capillary pipe clamp	universal	063002
3	550041	sensor clamp		063001



Item	Order	Description	Model	OEM
1	359027	signal lamp/green, 12mm	FE4-8, F4-10	076005
2	359048	signal lamp/yellow, 12mm		076006
3	359139	signal lamp/green, 9mm	F4-10	076025
4	359137	signal lamp/yellow, 9mm		076026



Item	Order	Description	Model	OEM
1	110482	knob/blue, 42mm	F8-F10	061037
2	110382	knob/black, 42mm		061050
3	110444	knob/blue, 55mm	FE4-8, F4, F6	061078
4	110499	symbol		082332



Item	Order	Description	Model	OEM
1	540747	drain tap	F10, F10+10	062001
2	970237	basket, 240x140x105mm	FE4, F4, F4+4	057115
3	970238	basket, 215x180x105mm	FE6, F6, F6+6	057607



Item	Order	Description	Model	OEM
1	970239	basket, 260x205x105mm	FE8, F8, F8+8	057604
2	970241	basket, 275x205x105mm	FE10	057106