

*Spare parts suitable for:*  
**ZANUSSI**





Wash and rinse systems

Page 4




Various and air traps

Page 6



Drain and filter systems

Page 8



Door and hood components

Page 11



Electrical components

Page 13



Dosing pumps

Page 19



Heating elements and boilers

Page 19




Pumps and components

Page 21

Suitable for Zanussi

## Wash and rinse systems




Item	Order	Description	Model	OEM
1	504500	wash arm		049044
2	504501	rinse arm		049049
3	504502	rinse arm spindle	LB1	049046
4	504503	lock nut	LB2, Z1, Z2,	049047
5	504504	wash arm bush	GW1, GW2	049042
6	504505	wash arm nut	W51, W52	049043
7	504506	nut/ wash arm support		049039
8	504507	gasket		049038



Item	Order	Description	Model	OEM
1	510119	wash arm, compl.		069576
2	510108	rinse arm spindle	LTB11, LTB12,	069445
3	510031	wash arm support	LTB22	069443
4	518036	gasket (outlet hose)		046878




Item	Order	Description	Model	OEM
1	510010	wash arm cross		69452
2	518382	wash arm/ right		
3	518385	wash arm/ left		
4	518384	rinse arm/ right	LTB11,	
5	518383	rinse arm/ left	LTB12,	
6	518004	wash jet	LTB22	069449
7	510131	union nut/ wash jet		069448
8	510139	rinse jet		069451
9	510130	union nut/ rinse jet		069450



Item	Order	Description	Model	OEM
1	510118	rinse arm, compl.		069577
2	518328	rinse arm/ right	LTB11,	
3	518329	rinse arm/ left	LTB12,	
4	510139	rinse jet	LTB22	069451
5	510130	union nut (rinse arm)		069450



Item	Order	Description	Model	OEM
1	510135	wash jet holder/ fixed arm		069640
2	510147	wash jet	LTB11,	069641
3	518482	union nut, wash jet	LTB12,	069642
4	510112	lock screw	LTB22	069440
5	518279	cover		069444



Item	Order	Description	Model	OEM
1	504508	wash arm cross		049293
2	504509	wash arm		049295
3	504510	rinse arm		049297
4	504511	rinse arm	LS5, LS32,	049298
5	504512	O-ring (rinse arm)	LS33	047473
6	504513	end cap (wash arm)		049296
7	504514	end cap (rinse arm)		049299



Item	Order	Description	Model	OEM
1	504515	protection (lock nut)		049294
2	504516	lock nut		047282
3	504517	nut (wash arm support)		048330
4	504537	gasket	LS5, LS32,	048236
5	504519	circlip	LS33	048979
6	504520	throttle disc		048820
7	504521	wash arm support/ lower		049290




Item	Order	Description	Model	OEM
1	504515	protection (lock nut)		049294
2	504516	lock nut		047282
3	504522	rinse arm spindle	LS5, LS32,	049292
4	504512	O-ring	LS33	047473
5	504523	nut (wash arm support)		048824
6	504524	gasket		048823




Item	Order	Description	Model	OEM
1	504535	wash arm		048247
2	504526	rinse arm		048716
3	504527	rinse arm spindle	LS10, LS12, LS14	048290
4	504528	lock nut		048632
5	504529	wash arm bearing		048401



Item	Order	Description	Model	OEM
1	504525	wash arm		048821, 048336
2	504526	rinse arm	LS6, LS7D,	048716, 048542
3	504527	rinse arm spindle	LS7, LS8D, LS8, LS62,	048290
4	504528	lock nut	LS63	048632
5	504529	wash arm bearing		048401



Item	Order	Description	Model	OEM
1	504536	nut (wash arm support)		048237
2	504537	gasket		048236
3	504519	circlip	LS10, LS12, LS14	048979
4	504530	throttle disc		048931
5	504539	wash arm support/ lower		048235



Item	Order	Description	Model	OEM
1	504517	nut (wash arm support)		048330
2	504537	gasket		048236
3	504519	circlip	LS6, LS7D, LS7, LS8D,	048979
4	504520	throttle disc	LS8, LS62,	048820
4	504530	throttle disc (L58/ old)	LS63	048645, 048931
5	504531	wash arm support/ lower		048819, 048329



Item	Order	Description	Model	OEM
1	504540	wash arm	LS360, LS365	068660
2	504541	rinse arm		046371
3	504516	lock nut	LS360,	047282
4	504543	rinse jet	LS365, LS540,	046272
5	504544	O-ring	LS720,	067898
6	504545	rinse jet holder	LS860	046273
7	504546	end cap		046266



Item	Order	Description	Model	OEM
1	504523	nut (wash arm support)		048824
2	504524	gasket	LS6	048823
3	504532	rinse arm	LS7D, LS7,	048333
4	504533	gasket	LS8D, LS8	046366
5	504534	wash arm support/ upper		046368



Item	Order	Description	Model	OEM
1	504547	lock nut (wash arm)		047283
2	504548	bush (wash arm)	LS360, LS365, LS540, LS720,	045771
3	504549	rinse arm spindle	LS860	046363
4	504550	wash arm bearing		046362

Suitable for Zanussi



Item	Order	Description	Model	OEM
1	504551	wash arm support/ lower	LS360, LS365,	046373
2	504552	O-ring	LS540, LS720, LS860	027301
3	504534	wash arm support/ upper	LS360, LS365, LS540, LS720	046368
4	504554	wash arm support/ upper	LS860	046547



Item	Order	Description	Model	OEM
1	504555	nut	LS540, LS720, LS860, LS1086	047891
2	504556	O-ring		047929
3	504557	junction	LS540	047893
4	504558	junction	LS720, LS860, LS1080	047907
5	504559	gasket		047928




Item	Order	Description	Model	OEM
1	504560	wash pipe	LS360, LS365	046400
2	504561	gasket		067768
3	n. l. a.	wash pipe	LS540	046374
3	504563	wash pipe	LS720, LS860, LS1080	046544
4	504564	O-ring		065506




Item	Order	Description	Model	OEM
1	504565	wash arm cross		047990
2	504566	wash arm		047470
3	504567	rinse arm/ short		048142
4	n. l. a.	rinse arm/ long	LS510,	047889
5	504512	O-ring (rinse arm)	LS520, LS521	047473
6	504570	end cap (rinse arm)		047475
7	504571	end cap (wash arm)		047471
8	504572	rinse jet		047927



Item	Order	Description	Model	OEM
1	504542	protection (lock nut)		047991
2	504516	lock nut	LS510,	047282
3	504573	rinse arm spindle	LS520,	047464
4	504574	O-ring	LS521	046376
5	504575	throttle disc		046361



Item	Order	Description	Model	OEM
1	504576	cover		048145
2	504577	O-ring/ inner	LS510,	047462
3	504578	O-ring/ outer	LS520,	045462
4	504579	wash arm support	LS521	047461



Item	Order	Description	Model	OEM
1	504573	rinse arm spindle		047464
2	504574	O-ring	LS510,	046376
3	504580	gasket	LS520,	046366
4	504534	wash arm support/ upper	LS521	046368

## Various



Item	Order	Description	Model	OEM
1	504582	X-piece		049073
2	504583	Y-piece		048195
3	504584	Y-piece		049289




Item	Order	Description	Model	OEM
1	504585	guard filter		048746
2	504586	guard filter		048834
3	504587	non-return valve		048414



Item	Order	Description	Model	OEM
1	516101	back flow restrictor		049332
2	510789	back flow restrictor		048191

Softeners



Item	Order	Description	Model	OEM
1	504045	salt container, compl.	LB1, LB2	049075
2	510929	salt container, compl.	LTB12, LTB22	069575, 069471
3	510032	salt container, compl.		069680



Item	Order	Description	Model	OEM
1	510015	cap		069467
2	510072	gasket	LTB12, LTB22	049245, 069468
3	510018	nut		069469
4	510071	gasket		049244, 069470



Item	Order	Description	Model	OEM
1	510109	cap		069472
2	510071	gasket	LTB11	069470
3	510110	nut		069552




Item	Order	Description	Model	OEM
1	505102	softener	LB1, LB2	049074
2	530000	softener	LTB11, LTB12	069476

Detergent components



Item	Order	Description	Model	OEM
1	504690	rinse aid container		049024
2	504691	hose connector		049026
3	504692	gasket	LB1, LB2	049201, 067292
4	504693	filter		049022
5	504694	spring		049023
6	504695	flap		049021



Item	Order	Description	Model	OEM
1	510100	container, compl./ connection on the side	LTB11, LTB12, LTB22	069521
2	510099	container, compl./ connection in the front		069547




Item	Order	Description	Model	OEM
1	510077	O-ring		069644
2	510105	connection fitting	LTB11, LTB12, LTB22	069646
3	510016	banjo bolt		069645
4	510014	gasket		069525



Item	Order	Description	Model	OEM
1	504696	container		049975
2	504691	hose connector		049026
3	504692	gasket	LS5, LS32, LS33	049201, 067292
4	504693	filter		049022
5	504697	spring		048279
6	504694	spring		049023
7	504698	flap		048363

Suitable for Zanussi




Item	Order	Description	Model	OEM
1	504690	container	LS6	049024
2	504699	hose connector		049941
3	504692	gasket		067292, 049292
4	504693	filter		049022
5	504697	spring		048279
6	504694	spring		049023
7	504698	flap		048363



Item	Order	Description	Model	OEM
1	504700	container	LS7	068630
2	504701	cap		068644
3	504702	suction tube		068650
4	504703	gasket		048434
5	504704	pin		068627
6	504705	spring		068645
7	504706	flap		048465




Item	Order	Description	Model	OEM
1	504707	container	LS32, LS33, LS61,	047549
2	504708	cap	LS62, LS63, LS64,	047551
3	504709	panel	LS510, LS520, LS521	047547



Item	Order	Description	Model	OEM
1	504710	nut	LS32, LS33, LS61, LS62, LS63, LS64, LS510, LS520, LS521	047550
2	504711	gasket		030186
3	504712	funnel		047548
4	504713	suction tube		047552

## Air traps



Item	Order	Description	Model	OEM
1	504617	air trap (drain pump)	LB1, LB2, LS5, LS6,	048853
2	504618	gasket	LS7, LS8, LS10,	068642
3	504619	hose clamp	LS12, LS14, LS33, LS63, LS64	046946



Item	Order	Description	Model	OEM
1	510103	air trap, compl.	LTB11, LTB12, LTB22	069515
2	510077	O-ring		069644
3	510105	connection for pump		069670
4	510017	union nut		0A6065
5	510016	banjo bolt		069646




Item	Order	Description	Model	OEM
1	504620	air trap	LS5, LS6, LS7, LS8, LS10,	048308
2	504618	gasket	LS12, LS14, LS32, LS33,	068642
3	504621	nut	LS61 - LS64	049268
4	504622	air trap	LS10 (old), LS12 (old), LS360,	046631
5	504623	O-ring	LS365, LS510, LS520, LS521	068573
6	504624	air trap	LS540, LS720, LS860, LS1080	045459
7	504623	shaft seal		068573


## Drain and filter systems



Item	Order	Description	Model	OEM
1	504588	drain plug	LB1, LB2	049914
2	504589	drain plug, drain pump		049915
3	504590	O-ring		049036



Item	Order	Description	Model	OEM
1	504591	filter		049032
2	504592	nut		049034
3	504593	O-ring	LB1, LB2	049033
4	504594	drain unit with air trap		049035



Item	Order	Description	Model	OEM
1	504595	filter	LS5, LS6, LS7,	048324
2	504596	nut	LS8, LS32,	048326
3	504597	gasket	LS33, LS62,	048327
4	504598	sump	LS63	048325




Item	Order	Description	Model	OEM
1	510038	drain plug		069526
2	518490	drain plug (drain pump)	LTB11,	
3	518491	O-ring	LTB12, LTB22	069527
4	510045	sump/filter compl.		069574




Item	Order	Description	Model	OEM
1	504599	drain plug		048250
2	504600	gasket	LS10, LS12,	048229
3	504601	inlet body	LS14	049600



Item	Order	Description	Model	OEM
1	510040	outer filter	LTB11, LTB12, LTB22	069528
2	510041	inner filter		069529



Item	Order	Description	Model	OEM
1	510433	drain plug + filter	LS360	068713
2	n. l. a.	drain plug	LS365	046635
3	504578	O-ring		045462
4	504604	inlet body	LS360, LS365	046396, 046395



Item	Order	Description	Model	OEM
1	518199	filter location	LTB11,	069530
2	510009	O-ring	LTB12,	069531
3	518201	inlet body	LTB22	069532



Item	Order	Description	Model	OEM
1	510434	drain plug + filter	LS540, LS720, LS860, LS1080	045476
2	504578	O-ring		045462
3	504605	inlet body	LS540, LS720	045458
4	504606	inlet body	LS860, LS1080	046525




Item	Order	Description	Model	OEM
1	510770	drain plug	LS5, LS6, LS7,	048323
2	510771	drain plug (drain pump)	LS8, LS32,	048842
3	510769	gasket	LS33, LS62, LS63	046799



Suitable for Zanussi



Item	Order	Description	Model	OEM
1	510768	drain plug	LS510, LS520	047460
2	504607	drain plug	LS521	047556
3	510769	O-ring		046799



Item	Order	Description	Model	OEM
1	504608	filter		047456
2	504609	O-ring	LS510, LS520, LS521	047458
3	504610	inlet body		047457

### Flat filters



Item	Order	Description	Model	OEM
1	504611	flat filter	LB1, LB2	049051
2	504612	flat filter	LS6	049908
3	504613	flat filter	LS10, LS12, LS14	048252



Item	Order	Description	Model	OEM
1	504614	flat filter	LS7, LS8, LS32, LS33, LS61 - 64	048332
2	504615	flat filter	LS510, LS520, LS521	047544



Item	Order	Description	Model	OEM
1	504616	drain seating	LS10, LS12, LS14	049633

### Hoses




Item	Order	Description	Model	OEM
1	504625	inlet hose	LB1, LB2	049041
2	518217	inlet hose	LTB11, LTB12, LTB22	069537
3	518216	outlet hose		046878




Item	Order	Description	Model	OEM
1	504626	inlet hose	LS5, LS6, LS7, LS8, LS32,	045768
2	504627	outlet hose	LS33, LS61 - LS64	046257



Item	Order	Description	Model	OEM
1	504628	inlet hose	LS360, LS365, LS510, LS520, LS521	045457
2	504629	outlet hose	LS360, LS365, LS510, LS520, LS521	046398
3	504627	outlet hose		046257



Item	Order	Description	Model	OEM
1	504628	inlet hose		048242
2	504629	outlet hose		045456
3	504626	inlet hose	LS10, LS12, LS14	045768
4	504630	outlet hose (old)		048241




Item	Order	Description	Model	OEM
1	504631	inlet hose		045456
2	504632	outlet hose	LS540, LS541, LS720, LS721	046372
3	504627	outlet hose		046257



Item	Order	Description	Model	OEM
1	504641	hinge/ left		049280
2	504640	hinge/ right		049279
3	504642	hinge pin		049281
4	504643	door stay		049282
5	504644	end stop		049286
6	504645	rod guide		049285




Item	Order	Description	Model	OEM
1	504633	inlet hose		046565
2	504634	outlet hose	LS860, LS861, LS1080	046542
3	504635	outlet hose		046546




Item	Order	Description	Model	OEM
1	504646	hinge lever/ right		048813
2	504647	hinge lever/ left	LS6, LS61, LS62,	048814
3	504648	bush	LS63, LS64	048812
4	504649	spring		048815

**Door components**



Item	Order	Description	Model	OEM
1	504636	plastic plate		049246
2	504637	spring jack	LB1, LB2	049030
3	504638	spring	LB1	049200
4	504639	spring	LB2	049086



Item	Order	Description	Model	OEM
1	504650	hinge/ right		048583
2	504651	hinge/ left		048582
3	504652	spring right	LS7	046269
4	504653	spring left		046268
5	504654	spring linkage		048581



Item	Order	Description	Model	OEM
1	518546	hinge/ right		069513
2	518547	hinge/ left	LTB11, LTB12,	
3	518256	hinge clamp/ right	LTB22	069514
4	518257	hinge clamp/ left		



Item	Order	Description	Model	OEM
1	504655	hinge/ right		046292
2	504656	hinge/ left		046291
3	504652	spring right	LS360, LS365, LS540, LS541	046269
4	504653	spring left		046268
5	504654	spring linkage		048581, 046267


Suitable for Zanussi




Item	Order	Description	Model	OEM
1	504657	hinge		048161
2	504658	hinge screw		047478
3	504659	catch housing	LS510, LS520, LS521	047491
4	504660	spring		047492
5	504661	door catch		047493




Item	Order	Description	Model	OEM
1	510068	catch	LTB11, LTB12,	069435
2	510069	door catch	LTB22	069436
3	504662	catch	LS5, LS32,	049271
4	504663	door catch	LS33	049536



Item	Order	Description	Model	OEM
1	504664	door frame	LS360, LS365	046392
2	504665	door frame	LS510, LS520, LS521	047483
3	504666	door frame	LS540	046270



Item	Order	Description	Model	OEM
1	504667	door seal/ upper	LB1, LB2	049017
2	504668	door seal/ lower		049016
3	504669	door seal/ upper	LS5, LS32, LS33	046583
4	504670	door seal/ upper	LS6	049932



Item	Order	Description	Model	OEM
1	504671	door seal/ upper	LS7	049248
2	504672	door seal/ upper	LS61 - LS64	048306
3	504673	door seal/ upper	LS360, LS365	046394



Item	Order	Description	Model	OEM
1	504674	door seal/ right	LS510, LS520, LS521	047454
2	504675	door seal/ left		047455

### Hood components




Item	Order	Description	Model	OEM
1	504676	handle support	LS720, LS860, LS1080	046537
2	504677	bush		046538
3	504678	handle support	LS12 (old)	049430
4	504679	screw		048349




Item	Order	Description	Model	OEM
1	504680	handle support	LS12, LS14	049597
2	504681	roller		049598



Item	Order	Description	Model	OEM
1	504682	spring	LS720	046615
2	504683	spring	LS860, LS1080	046540
3	504684	spring	LS8	048655




Item	Order	Description	Model	OEM
1	504685	spring	LS10, LS12, LS14	049582
2	504686	spring	LS10 (old), LS12 (old)	048258
3	504687	spring	LS14EA/ AU	049947




Item	Order	Description	Model	OEM
1	504688	spring compressor	LS720, LS860, LS1080, LS8, L10 (old), LS12 (old)	075767
2	504689	spring compressor	LS10, LS12, LS14	049583


Electrical components




Item	Order	Description	Model	OEM
1	400915	fascia	LS5	049956
2	400916	display p.c.b.		0L0047
3	400917	main p.c.b.		0L0046




Item	Order	Description	Model	OEM
1	400918	fascia	LS6	049920
2	400919	display p.c.b.		049897
3	400920	main p.c.b.		049910, 0L0045




Item	Order	Description	Model	OEM
1	400921	fascia	LS10EA	0L0008
2	400922	fascia	LS14EA	0L0001
3	400923	display p.c.b.	LS10EA,	049998
4	400920	main p.c.b.	LS14EA	0L0045
4	400961	main p.c.b.		0L0541




Item	Order	Description	Model	OEM
1	400924	fascia	LS10	049605
2	400925	fascia	LS12	049606
3	400926	fascia	LS12AU	049604



Item	Order	Description	Model	OEM
1	400927	display p.c.b.	LS10, LS12	049623, 049754
2	400920	main p.c.b.		049622, 049752, 0L0045



Item	Order	Description	Model	OEM
1	400928	main p.c.b.	LS61, LS62	048833
2	400929	main p.c.b.	LS63, LS64	048926



Item	Order	Description	Model	OEM
1	400930	main p.c.b.	LS8DP	049150
2	400931	main p.c.b.	LS10DP	049141
3	400932	main p.c.b.	LS12DP	049147



no picture!


2

Item	Order	Description	Model	OEM
1	360275	timer p.c.b.	LS32	049411
2	360276	timer p.c.b.	LS33	049412




Item	Order	Description	Model	OEM
1	379901	sensor	LS5, LS6	049884
2	379902	sensor	LS5, LS6,	049643
3	504574	gasket	LS10, LS12,	046376
4	504753	holder	LS14	049580

Fasciae



Item	Order	Description	Model	OEM
1	504714	fascia	LB1, LB2	049061
2	504715	fascia	LS7	048339
3	504716	fascia	LS32, LS33	049313

Suitable for Zanussi



Item	Order	Description	Model	OEM
1	504717	fascia	LS61, LS62	048827
2	504718	fascia	LS63	048903
3	504719	fascia	LS520	047545 047633




Item	Order	Description	Model	OEM
1	504720	fascia	LS521	047561 047633
2	504721	fascia	LS540, LS720	046345
3	504722	fascia	LS860	046732




Item	Order	Description	Model	OEM
1	504723	fascia	LS8	048648
2	504724	fascia	LS8DP	049151
3	504725	fascia	LS10	048470




Item	Order	Description	Model	OEM
1	504726	fascia	LS10	048590
2	504727	fascia	LS10DP	049143
3	504728	fascia	LS12	048473




Item	Order	Description	Model	OEM
1	504729	switch panel	LS12DP	049148
2	504730	switch panel	LS12HD	048598
3	504731	gasket	universal	048274



Item	Order	Description	Model	OEM
1	345831	switch		049063
2	345832	push button	LB1, LB2	049068
3	345833	push button		049062
4	345834	push button		049065
5	345836	signal lamp		049064



Item	Order	Description	Model	OEM
1	345005	switch combination	LTB11	069412
2	345006	switch combination	LTB12, LTB22	069413



Item	Order	Description	Model	OEM
1	359001	signal lamp	LTB11, LTB12,	069415
2	359002	signal lamp	LTB22	
3	359003	signal lamp		069418
4	359006	signal lamp	LTB12, LTB22	069417



Item	Order	Description	Model	OEM
1	345824	switch	LS32, LS33	049316
2	345825	push button		049315
3	345826	switch	LS33	049326




Item	Order	Description	Model	OEM
1	345827	push button/ grey	LS32, LS33	049317
2	345828	push button/ yellow		049318
3	345829	push button	LS33	049325
4	345830	blind cap	LS32, LS33	049314




Item	Order	Description	Model	OEM
1	359130	signal element/green		048832
2	359126	socket/green		075096




Item	Order	Description	Model	OEM
1	359130	signal element, 230V		046241
1	359132	signal element/ green, 230V		046076
2	359127	socket/ yellow	LS360, L365, LS510, LS520,	075095
3	359126	socket/ green	LS521	075096
4	359792	socket/ blue		047750
5	359225	socket/ clear		046289



Item	Order	Description	Model	OEM
1	345169	main switch		048829
2	345168	program switch		048828
3	504732	gasket	LS61, LS62,	046360
4	110907	knob	LS63, LS64	048830
5	504733	grub screw		047846
6	359130	signal element		048832
7	359126	socket/ green		075096




Item	Order	Description	Model	OEM
1	301183	rotary switch		046350
2	504732	gasket	LS540, LS541,	046360
3	110911	knob	LS720, LS860,	046356
4	504733	grub screw	LS1080	047846




Item	Order	Description	Model	OEM
1	301087	rotary switch		047498
2	301180	rotary switch		047560
3	504732	gasket	LS510, LS520, LS521	046360
4	110910	knob		047842
5	504733	grub screw		047846




Item	Order	Description	Model	OEM
1	359130	signal element		048832
1	359132	signal element/ green, 230V	LS540, LS541, LS720, LS860,	046076
2	359225	socket/ clear	LS1080	046289
3	359126	socket/ green		075096
4	359792	socket/ blue		047750



Item	Order	Description	Model	OEM
1	301181	rotary switch	LS360	047360
2	301182	rotary switch	LS365	046649
3	504732	gasket		046360
4	110911	knob	LS360, LS365	046356 Z
5	504734	grub screw		046258



Item	Order	Description	Model	OEM
1	345021	switch	LS540, LS541,	045165, 046348
2	504735	gasket	LS720, LS860, LS1080,	046298
3	345744	push button	LS360, LS365	046293



Item	Order	Description	Model	OEM
1	345171	main switch	LS7, LS10 (to Nr 304_), LS12 (to Nr 304_)	048271
2	345172	main switch	LS8, LS10 (from Nr 305_), LS12 (from Nr 305_)	048524
3	345170	program switch	LS7, LS8, LS10	048270

Suitable for Zanussi



Item	Order	Description	Model	OEM
1	301184	program switch	LS12	048286
2	301185	main switch	LS7DP	048828
3	301186	main switch	LS8DP, LS10DP, LS12DP	049144
4	301187	program switch	LS7DP, LS8DP, LS10DP, LS12DP	049145




Item	Order	Description	Model	OEM
1	504732	gasket		046360
2	110912	knob	LS7	048340
3	110913	knob	LS8, LS10, LS12	048402
4	504733	grub screw		047846




Item	Order	Description	Model	OEM
1	359130	signal element, 230V	LS7, LS8	048488
1	359132	signal element/green, 230V	LS10, LS12	048832
2	359126	socket/green		075096


### Timers




Item	Order	Description	Model	OEM
1	360279	120"/ 300", 7 cams, 230V	LB1, LB2 (to Nr 716)	49054
2	360278	120"/ 300", 7 cams, 230V	LB1 (from Nr 717), LB2 (from Nr 717)	49256
3	360277	regeneration, 230V	LB1, LB2	49251



Item	Order	Description	Model	OEM
1	360024	120", 230V	LTB11, LTB12, LTB22	069419, 069669
2	360005	20", 230V (regeneration)		069420



Item	Order	Description	Model	OEM
1	360283	230V	LS360, LS365	068671
2	360039	180", 4 cams, 230V	LS510, LS520, LS521	047497, 048881



Item	Order	Description	Model	OEM
1	360280	230V	LS720	046621
2	360281	230V	LS860	046733



Item	Order	Description	Model	OEM
1	360071	5 cams, 230V	LS7	48303
2	360073	5 cams, 230V	LS8	48647
3	360074	6 cams, 230V	LS10, LS12	48591, 48264

### Pressure switches



Item	Order	Description	Model	OEM
1	541177	110/ 55, 165/ 135 (drain pump)	LB1, LB2	049081
2	541171	110/ 55		049058
3	541003	55/ 35	LTB11, LTB12, LTB22	069434




Item	Order	Description	Model	OEM
1	541006	60/ 20	LS360, LS510, LS520, LS540, LS7, LS8	049485, 046352, 048723
2	541007	68/ 54	LS365	046648
3	541172	110/ 85 - 60/ 20	LS521	048752




Item	Order	Description	Model	OEM
1	541008	105/ 60	LS720, LS860, LS1080	046601
2	541173	2 levels	LS7DP, LS8DP, LS61, LS62, LS63, LS64	048826
3	541178	250/ 130 - 390	LS10, LS12, LS12DP, LS14	049620 (electronic control)




Item	Order	Description	Model	OEM
1	541179	240/ 130	LS10, LS12	048267
2	541174	2 levels	LS10DP, LS12DP	049142




Item	Order	Description	Model	OEM
1	541175	60/ 20	LS32	049305, 049881
2	541176	110/ 80 - 60/ 20	LS32 (from Nr 731_), LS33 (from Nr 731_)	049361




Item	Order	Description	Model	OEM
1	390004	30 - 90 °C (boiler)	LTB11, LTB12,	069422
2	390005	0 - 85 °C (tank)	LTB22	069423



Item	Order	Description	Model	OEM
1	375210	30 - 90 °C (boiler)	LB1, LB2	049191
2	390467	82 °C fixed (boiler)	LS32, LS33	049255



Item	Order	Description	Model	OEM
1	390038	30 - 90 °C (boiler)	LS360, LS365	045169
2	375061	30 - 90 °C (boiler)	LS360, LS365D	46413



Item	Order	Description	Model	OEM
1	390030	30 - 90 °C (boiler)	LS7, LS8, LS10, LS12, LS540, LS720, LS860, LS1080, LS61 - LS64	048266, 068012, 049243
2	390165	safety thermostat, 140 °C (boiler)	LS520D, LS521D, LS540, LS720, LS860, LS1080	051644

Thermostats




Item	Order	Description	Model	OEM
1	390101	contact thermostat	LS360, LS365, LS510, LS520, LS521, LS540, LS720, LS860, LS1080, LS7, LS8, LS10, LS12	045495, 048487, 047508
2	390466	contact thermostat	LS510, LS520, LS521	048166, 048631



Item	Order	Description	Model	OEM
1	390468	contact thermostat (tank)	LS - DP, LB1, LB2, LS32, LS33, LS61 - LS64	48804
2	390138	safety thermostat, 112 °C (boiler)	LB1, LB2, LS32, LS33, LS61 - LS64, LS7, LS8,	048887, 048287
3	504736	support plate	LS10, LS12	048987




Suitable for Zanussi




Item	Order	Description	Model	OEM
1	504544	O-ring	universal	067898
2	504738	screw		067899
3	510417	gasket	LTB11, LTB12, LTB22	
4	521134	nut, M14 x 1		

### Micro switches




Item	Order	Description	Model	OEM
1	345257	micro switch	LTB11, LTB12, LTB22	069484
2	345254	micro switch	LS360, LS365, LS510, LS520, LS521, LS540	047485, 046286, 046379
3	345815	micro switch	LS720, LS860, LS1080	060722



Item	Order	Description	Model	OEM
1	345816	magnetic switch	LB1, LB2, LS8, LS10, LS12	048486
2	345117	magnetic switch	LS7 (to 1994)	048392
3	345818	magnetic switch	LS7 (from 1994)	048893




Item	Order	Description	Model	OEM
1	345819	magnetic switch	LS7DP, LS8DP, LS10DP, LS12DP, LS61, LS62, LS63, LS64	048831
2	345820	magnetic switch	LS32, LS33	049226
3	345821	electronic control	LS5, LS6, LS10, LS12, LS14, LS10DP	049621




Item	Order	Description	Model	OEM
1	345822	magnetic switch/level regulator	LS8, LS10, LS12	049478
2	345823	limit switch	LS720, LS860, LS1080	048159


### Solenoid valves



Item	Order	Description	Model	OEM
1	370019	double, 230V	LB1, LB2	049056
2	370023	triple, 230V		049077




Item	Order	Description	Model	OEM
1	370021	double, 230V	LTB11	069463
2	370025	triple, 230V	LTB12, LTB22	069464



Item	Order	Description	Model	OEM
1	370016	single, 230V	LS7, LS8, LS10, LS12, LS510, LS520, LS521, LS540, LS720, LS860, LS1080, LS5, LS61 - LS64	047529, 048178, 047843, 046320, 048898, 048817, 048894
2	370022	double, 230V	LS_HD	049230


### Relays



Item	Order	Description	Model	OEM
1	380183	2 changeover, 12 A (AC1)	LB1, LB2, LS7, LS10 (to Nr 304_), LS12 (to Nr 304_)	48438
2	380196	4 changeover, 12 A (AC1)	LB1, LB2, LS10 (from Nr 305_), LS12 (from Nr 305)	48611
3	380131	3 changeover, 16 A (AC1)	LS360, LS365, LS540, LS720, LS860, LS1080	046380



Item	Order	Description	Model	OEM
1	380318	2 NO, 16A (AC1)	LS7DP, LS8DP, LS10DP, LS12DP, LS32, LS33, LS61 - LS64	048888
2	380622	time relay, 0,05 sec - 60 h (multifunction)	LS_HD	049235
3	380136	base		049236



Item	Order	Description	Model	OEM
1	380203	3 NO/ 1 NC, 230V	LS7, LS8, LS10, LS12, LS14, LS32/4,5, LS33/4,5, LS61 - LS64	048403, 048825
2	380204	230V	LS540, LS720, LS860, LS1080	075796, 082986

**Dosing pumps**



Item	Order	Type	Model	OEM
1	361370	Glados, diaphragm	LB1, LB2, LS5, LS32, LS33, LS7 (from Nr 545_), LS8 (from Nr 545_), LS10 (from Nr 242_), LS12 (from Nr 242_)	048715, 049484
2	361008	Lang, diaphragm	LS10 (to Nr 241_), LS12 (to Nr 241_9, LS360, LS365, LS510, LS520, LS521, LS540, LS720, LS860, LS1080	048498, 045478



Item	Order	Type	Model	OEM
1	361004	DB2, 230V (electrical)	LTB11, LTB12, LTB22	069478, 069921
2	361113	solenoid coil, DB2		049625
3	361013	Lang, 230V (electrical)		048580



Item	Order	Typ	Model	OEM
1	361152	detergent (dosing pump)	LS6, LS10,	049624
2	361150	rinse aid (dosing pump) 0,4 l	LS12, LS14	
2	361151	rinse aid (dosing pump) 1,5 l	(electronic control)	049625




Item	Order	Description	Model	OEM
1	361141	bottle weight/filter		049356
2	361270	chemical feed elbow		049557
3	361147	non-return valve		



Item	Order	Description	Model	OEM
1	361134	hose (detergent)		049149
2	361135	hose (rinse aid)		049148

**Heating elements**

Tank heating elements



Item	Order	Description	Model	OEM
1	415010	2000W, 230V	LTB11, LTB12, LTB22	069437, 069671
2	415272	800W, 230V	LB1, LB2	049059
3	415070	2200W, 230V	LS6, LS7, LS8, LS10, LS12, LS32, LS33, LS61 - LS64	048228, 048924
3	416133	2000W, 230V	LS5	049954

Suitable for Zanussi



Item	Order	Description	Model	OEM
1	416132	3000W, 230V	LS10EA, LS14	048491
2	415072	2200W, 230V	LS360, LS365, LS520D, LS521D, LS720, LS860, LS1080	046404, 046418, 048000, 048086
3	415073	2200W, 230V	LS510, LS520, LS521, LS540	046284, 047507, 047848, 047506



Item	Order	Description	Model	OEM
1	415068	6000W, 3 phases 230V	LS7, LS8, LS10	048513, 048221
2	416129	6000W, 3 phases 230V	LS6	048898
3	416131	4500W, 3 phases 230V	LS32, LS33, LS540D, LS720D, LS860D	049307, 052905, 026453

Tank heating elements/ Accessories




Item	Order	Description	Model	OEM
1	510416	gasket		069438
2	520231	nut, M10 x 1		
3	521132	O-ring	universal	046223
4	521133	nut, M14 x 1		046223
5	510387	gasket		
6	510388	flange		048483



Item	Order	Description	Model	OEM
1	415066	4500W, 230V		047847
2	415080	6000W, 230V	LS520D, LS521D	
3	416134	10500W, 230V	LS10EA, LS14	049997

Boiler elements



Item	Order	Description	Model	OEM
1	415002	3000W, 230V	LTB11, LTB12, LTB22	069455, 069672
2	415174	3000W, 3 phases 230V	LB1, LB2, LS62 - LS64	048927
3	416130	2800W, 230V	LS32, LS33	049371



Item	Order	Description	Model	OEM
1	415597	3000W, 3 phases 230V	LS510, LS520, LS521	066109, 047505
2	415069	4500W, 3 phases 230V	LS360, LS720, LS860	065557, 045518, 046623, 046627
3	415379	6000W, 3 phases 230V	LS1080	051632, 066110



Item	Order	Description	Model	OEM
1	416135	2800W, 230V	LS5	049980
2	416128	4500W, 3 phases 230V	LS5	049955
3	415067	4500W, 3 phases 230V	LS7/ 9, LS8/ 9, LS12	048928, 048284



Item	Order	Description	Model	OEM
1	510408	O-ring		003362
2	520236	flange		065558

**Boilers**




Item	Order	Description	Model	OEM
1	504739	boiler	LB1, LN2	049053
2	504740	boiler	LTB11, LTB12, LTB22	069453
3	504741	boiler	LS360, LS365	046294



Item	Order	Description	Model	OEM
1	504750	boiler	LS10EH, LS14	049987
2	504751	boiler	LS10, LS12 (electronic control)	049632

**Pumps**

Drain pumps



Item	Order	Description	Model	OEM
1	500392	34W, 230V	LB1, LB2, LS33, LS63, LS64, LS6_DP, LS7DP, LS8DP, LS10DP, LS12DP	048844
2	500207	90W, 230V	LS365	046647
3	500206	90W, 230V	LS521	047562

**Booster pumps**




Item	Order	Description	Model	OEM
1	500393	350W, 230V	LB1, LB2, LS32, LS33, LS62HD	048910
2	500394	280W, 230V	LS6EA, LS10/LS12/LS14 - (electronic control)	049310
3	500395	350W, 230V	LS8HD, LS10HD, LS12HD	049229

**Wash pumps**



Item	Order	Description	Model	OEM
1	500129	280W, 230V	LB1, LB2	049057
2	500003	290W, 230V	LTB11, LTB12, LTB22	069450, 069804, 069675, 069805
3	500114	740W, 230V	LS32, LS33, LS61 - LS64, LS7DP, LS8DP	048885


no picture!



Item	Order	Description	Model	OEM
1	504742	boiler	LS510, LS520, LS521	048194
2	504743	boiler	LS540	048197
3	504744	boiler	LS720, LS860, LS1080	047950



Item	Order	Description	Model	OEM
1	504745	boiler	LS32, LS33	049336
2	504746	boiler	LS61, LS6EP, LS7, LS8, LS10	048548, 048341
3	504747	boiler	LS62, LS63, LS64, LS7/9, LS8/9, LS12	048484, 048727



Item	Order	Description	Model	OEM
1	504748	boiler	LS5	049958
2	504749	boiler	LS6	049902


Suitable for Zanussi




Item	Order	Description	Model	OEM
1	500090	550W, 230V	LS360, LS365, LS510, LS520, LS521	046370
2	500396	750W, 230V	LS5, LS6	049876
3	500113	740W, 230V (3 ph)	LS7, LS8	048304



Item	Order	Description	Model	OEM
1	500397	1kW, 400V, (3 ph)	LS860, LS1080	047708
2	500115	1,5 kW, 400V, (3 ph)	LS10, LS12, LS14	048216



Item	Order	Description	Model	OEM
1	500112	550W, 230V	LS540D	046574
2	500056	550W, 400V (3 ph)	LS540D, LS720	046346



Pumps		1 Impellor		2 Mechanical seal		3 Housing gasket		4 Pump cover		5 Capacitor	
Order	OEM	Order	OEM	Order	OEM	Order	OEM	Order	OEM	Order	OEM
500003	069804	510615	69545	510693	69543	510554	69544	510512	-	365013	69541
500056	046346	510601		510693		510551		510502		--	
500090	046370	521237		510692		521709		521531		365014	
500112	046574	510601		510693		510551		510502		--	
500113	048304	521271		510692		521709		521531			
500114	048885	509021		510692		521709		521531		365021	
500115	048216	510602		510693		510551		521515		--	
500129	049057	521227		510692		521705		521522		365012	
500394	049310	521206		510695		509002		510384		365012	
500396	049876	521208		510692		521702		521506		365021	
500397	047708	521216		510693		510551		521514	48059	--	